

Maintenance Section



VT* & VS

500 • 605 • 650 • 800

Range of Twin Engine
& Hydrostatic Sweepers

From Manufacture

Sequence No. 07/2057

* With Stage 3a/Tier 3 Auxiliary Engines

Part No 02617-4-M

Revision Level 16

Page Issue Levels	P
Scheduled Maintenance	7
Hydraulic System	8
Electrical System	9
Water System	10
Pneumatic System	11
Wearing Items	12
Remove and Refit Procedures	13
Fault Diagnosis	14
Service Tools	15
Warranty	16
Health and Safety	17

CHAPTER

P

Page Issue Levels

Description

This chapter lists each page in the Maintenance section, it's issue level and whether it has changed since the previous revision level. Changed pages are indicated by the letter 'C' in the changed column, and new pages by the letter 'N'.

P Chapter - Page Issue Levels

Page	Issue	Changed	Page	Issue	Changed
P1	16	C	P2	16	C
P3	16	C	P4	16	C

7 Chapter - Scheduled Maintenance

Page	Issue	Changed	Page	Issue	Changed
7:1	05		7:2	01	
7:3	01		7:4	08	
7:5	08		7:6	10	
7:7	05		7:8	12	
7:9	08		7:10	05	
7:11	05		7:12	05	
7:13	05		7:14	05	
7:15	05		7:16	05	
7:17	05		7:18	05	

8 Chapter - Hydraulic System

Page	Issue	Changed	Page	Issue	Changed
8:1	01		8:2	01	
8:3	04		8:4	01	
8:5	01		8:6	01	
8:7	01		8:8	01	
8:9	12		8:10	16	C
8:11	16	C	8:12	01	
8:13	01		8:14	03	
8:15	02		8:16	16	C
8:17	01		8:18	01	
8:19	12		8:20	16	C

9 Chapter - Electrical System

Page	Issue	Changed	Page	Issue	Changed
9:1	05		9:2	01	
9:3	01		9:4	02	
9:5	15		9:6	12	
9:7	02		9:8	02	
9:9	02		9:10	02	
9:11	02		9:12	02	
9:13	09		9:14	09	
9:15	05		9:16	05	
9:17	05		9:18	05	
9:19	05		9:20	05	
9:21	05		9:22	05	
9:23	05		9:24	05	
9:25	05		9:26	05	

Copyright and rights are the property of Johnston Sweepers Ltd.

Copyright and rights are the property of Johnston Sweepers Ltd.

9 Chapter - Electrical System continued

Page	Issue	Changed	Page	Issue	Changed
9:27	05		9:28	05	
9:29	05		9:30	05	
9:31	05		9:32	05	
9:33	13		9:34	05	
9:35	05		9:36	05	
9:37	05		9:38	05	
9:39	08		9:40	05	
9:41	05		9:42	05	
9:43	09		9:44	09	
9:45	09		9:46	09	
9:47	09		9:48	09	
9:49	09		9:50	15	
9:51	07		9:52	09	
9:53	09		9:54	09	
9:55	08		9:56	08	

10 Chapter - Water System

Page	Issue	Changed	Page	Issue	Changed
10:1	12		10:2	01	
10:3	01		10:4	01	
10:5	01		10:6	01	
10:7	01		10:8	12	
10:9	12		10:10	12	
10:11	12		10:12	12	
10:13	12		10:14	12	
10:15	12		10:16	12	
10:17	13		10:18	12	

11 Chapter - Pneumatic System

Page	Issue	Changed	Page	Issue	Changed
11:1	01		11:2	01	
11:3	01		11:4	01	
11:5	01		11:6	01	
11:7	07		11:8	07	
11:9	01		11:10	01	
11:11	12		11:12	04	
11:13	07		11:14	04	
11:15	09		11:16	09	

12 Chapter - Wearing Items

Page	Issue	Changed	Page	Issue	Changed
12:1	01		12:2	09	
12:3	14		12:4	01	
12:5	01		12:6	01	
12:7	01		12:8	01	

13 Chapter - Remove and Refit Procedures

Page	Issue	Changed	Page	Issue	Changed
13:1	01		13:2	01	
13:3	01		13:4	01	
13:5	01		13:6	14	
13:7	08		13:8	01	

14 Chapter - Fault Diagnosis

Page	Issue	Changed	Page	Issue	Changed
14:1	01		14:2	01	
14:3	01		14:4	16	C
14:5	01		14:6	01	
14:7	01		14:8	01	
14:9	01		14:10	01	

15 Chapter - Service Tools

Page	Issue	Changed	Page	Issue	Changed
15:1	01		15:2	13	
15:3	01		15:4	01	
15:5	01		15:6	01	
15:7	01		15:8	01	
15:9	01		15:10	01	
15:11	01		15:12	01	
15:13	01		15:14	01	
15:15	01		15:16	01	

16 Chapter - Warranty

Page	Issue	Changed	Page	Issue	Changed
16:1	01		16:2	10	
16:3	10		16:4	10	
16:5	03		16:6	01	

17 Chapter - Health and Safety

Page	Issue	Changed	Page	Issue	Changed
17:1	01		17:2	01	
17:3	01		17:4	01	
17:5	01		17:6	01	
17:7	01		17:8	01	

Copyright and rights are the property of Johnston Sweepers Ltd.

CHAPTER

7

Scheduled Maintenance**Table of Contents**

Section	Page
Introduction	
Regular Maintenance	7 : 2
Security of Sweeping Equipment	7 : 3
Circuit Diagram Finders	
Fluid (Hydraulic, Pneumatic, Water) Circuits	7 : 4
Electrical Circuits	7 : 5
Auxiliary Engine	
Fuel System Bleeding - VT	7 : 6
Throttle Settings	7 : 7
Fluid Flywheel - VT	
Maintenance	7 : 9
Filling and Draining Instructions	7 : 9
Hydraulics	
Hydraulic Oil Reservoir - VT	7 : 10
Hydraulic Oil Reservoir - VS	7 : 11
Pneumatics	
Filter regulator Unit	7 : 12
Body/Cowl	
Cowl Silencer Assembly	7 : 13
Body Roof Duct	7 : 13
Additional Information	
VS Range	7 : 15

INTRODUCTION

REGULAR MAINTENANCE

It is impossible to over emphasise the importance of regular maintenance, inspection and running adjustments to maintain efficiency and obtain trouble free service from the machine.

Attention is drawn to the recommendation in the Auxiliary Engine Handbook relating to the post delivery check over.

The maintenance schedule specified are for average operating conditions. Under particularly dry and dusty conditions, it is essential that more frequent attention is given to:

- 1 Air cleaner servicing.
- 2 Engine oil changes.
- 3 Fluid oil changes.
- 4 Gearbox oil changes.
- 5 Hydraulic oil changes.

A flap is provided in the rear valance of the engine mounting tub to give access to the engine when carrying out servicing and for cleaning spilt oil etc. from under the tub floor which could be a fire hazard.

Attention to the servicing of air cleaners fitted to both auxiliary and vehicle engines is of vital importance as clean air is essential for the proper functioning and ultimate life of an engine. Badly serviced air cleaners can allow dust particles to be directly induced into the internal working surfaces with a resulting rapid increase in engine wear and eventually complete failure. This also applies to any air leaks occurring between the air cleaner and the engine inlet manifold. See separate instructions for Air Cleaner Servicing.

It is important that the following Safety Precautions are observed when working on the machine.



Safety Precautions




- Ensure the machine is standing on firm, level ground and there are no obstructions above or to the rear before raising the body.
- Ensure the safety prop is used at all times when working under the body.
- Ensure operators are fully conversant with the controls and operation.
- Isolate the air in the systems locker before working on any pneumatically operated or controlled equipment.
- Disconnect or isolate the vehicle battery when working on the electrical system.
- Ensure the auxiliary engine is switched off once the channel brush has been lowered for adjustment.
- Be aware of the safety instructions relative to the suction fan given in the equipment maintenance notes.
- Keep hands, loose clothing, hair etc. well clear of moving parts.
- Do not climb on the engine walkways unnecessarily or approach the fan inlet whilst the engine is running.
- Do not grasp any part of the engine or exhaust system without first ascertaining whether it has cooled sufficiently to avoid scalding.
- Do not use ill-fitting tools such as spanners that may slip and cause injury.
- Use approved safety platforms/gantries when working above ground level. Get a second person to check periodically when only one person is working on access equipment or inside the body.
- The use of 'needle stick gloves' is recommended when changing brushes, using the wanderhose/Littasnatch and when cleaning out the machine.

SECURITY OF SWEEPING EQUIPMENT

It is necessary to check every six months the security of various components as part of the maintenance programme.

These fixings are detailed on the illustration below.



95MA. 024

'A' = M12 Standard 'B' = M12 Grade 10.9 'C' = M14 Grade 10.9
'D' = M12, M14 Grade 10.9 or M16 Standard depending on chassis

Torque Settings


M12 Standard = 95 Nm (70 lbf/ft)	M14 Grade 10.9 = 215 Nm (160 lbf/ft)
M12 Grade10.9 = 135 Nm (100 lbf/ft)	M16 Standard = 235 Nm (150 lbf/ft)

CIRCUIT DIAGRAMS

A chart can be found overleaf to assist in finding the circuit diagram required.

The actual circuit diagrams will be found in the appropriate chapter.

Copyright and rights are the property of Johnston Sweepers Ltd.

Fluid Finder - Diagram SF500z02


Johnston
SWEEPERS LIMITED
GENTS ROAD, DORKING, SURREY, UK. RH4 1JF

IT IS AN INSTRUMENT OF THE DRAWING AND DESIGN AND IS NOT TO BE USED IN ANY OTHER MANNER WITHOUT THE WRITTEN CONSENT FROM JOHNSTON SWEEPERS LIMITED.

TITLE
FLUID FINDER DIAGRAM

<small>PROJ. NO.</small> D24828	<small>REVISED BY</small> V RANGE
<small>DATE</small> 06/11/08	<small>REVISED BY</small> V RANGE
<small>PROJ. NO.</small> SF500z02	<small>REVISED BY</small> V RANGE
<small>DATE</small> 05	<small>REVISED BY</small> V RANGE

OPTIONAL EQUIPMENT SHOWN IN ITALIC TEXT

Copyright and rights are the property of Johnston Sweepers Ltd.

Type B - Electrical Diagram Index - SE550z10

Copyright and rights are the property of Johnston Sweepers Ltd.

- SE550z10 Diagram Index
- SE550z11 Component Index
- SE550z12 Component Identification
- SE551z04 System Map
- SE552z04 Switch Panel
- SE553z04 Relay Panel
- SE553z02 Diode Pack
- SE554z02 Fuse / Main Relay
- SE555z03 Program / Discharge Select
- SE556z03 Discharge Control
- SE557z03 Beacon
- SE558z03 Worklamps & Marker Lights
- SE559z02 Instrument Panel
- SE561z03 Channel Brush - Single
- SE562z03 Channel Brush - Dual
- SE563z03 Nozzle - Single (+ Combivac Nozzle Option)
- SE564z03 Nozzle - Dual (+ Combivac Nozzle Option)
- SE565z03 Wide Sweep Brush - Single
- SE566z03 Wide Sweep Brush - Dual
- SE567z02 Intake Flaps
- SE568a01 Powaboom - VT & VS Standard
- SE571z03 Variabrush / Rotatilt Option
- SE572z03 Independant / Simultaneous Sweep Option
- SE573z03 Recirculating Water Option
- SE574z03 Varagap Option
- SE575z03 Supawash Option
- SE578a01 Additional Throttle Option - VT & VS Standard
- SE579z03 Additional Wide Sweep Brush Water Option
- SE580z03 Auxiliary Program Button/Maxigap/Varagap
- SE585z04a Hydrostatic - Switch Panel
- SE585z04b Hydrostatic - D-Tec Control Box
- SE585z04c Hydrostatic - Powerpack
- SE587z03a Iveco Stage 3HP Auxiliary Engine - Switch Panel
- SE587z03b Iveco Stage 3HP Auxiliary Engine - Powerpack
- SE587z03c Iveco Stage 3HP Auxiliary Engine - Management Box
- SE588z03a John Deere 125 HP Tier 3 Auxiliary Engine - Switch Panel
- SE588z03b John Deere 125 HP Tier 3 Auxiliary Engine - Powerpack
- SE588z03c John Deere 125 HP Tier 3 Auxiliary Engine - Management Box
- SE589z03a Iveco Stage 3 SP Auxiliary Engine - Switch Panel
- SE589z03b Iveco Stage 3 SP Auxiliary Engine - Powerpack/Man Box
- SE590z03 John Deere Tier 3 Auxiliary Engine
- SE685z03 Front Brush System Dual
- SE686z03 Front Brush System Single
- SE687z03 Water Pump Bypass (Option)



IT IS AN INFRINGEMENT OF THE COMPANY'S COPYRIGHT IN THIS DRAWING AND DESIGN TO COPY OR COMMUNICATE ITS CONTENTS TO ANY THIRD PARTY WITHOUT WRITTEN CONSENT FROM JOHNSTON SWEEPERS LIMITED.

TITLE: ELECTRICAL CIRCUIT DIAGRAM INDEX FOR TYPE B STAGE 3A ENGINES

ENCL: ED24626	DRAWN BY: SJA	DATE: 08/11/08
MODEL: VT & VS	REVISION: SE550z10	05

Please refer to the Operator's Guide, Chapter 6, for the Routine Maintenance Schedules.

The following items are not covered in the Operator's Guide.

MAINTENANCE AND ADJUSTMENT INSTRUCTIONS



AUXILIARY ENGINE - FUEL SYSTEM BLEEDING

IVECO - HP Turbo Charged



Under no circumstances should injector pipes be loosened and the engine cranked. This engine uses very high injection pressures and will cause injury. The system is self priming by using the manual plunger on the top of the fuel filter.

A = Manual Fuel Primer




95MA. 002

When starting the engine for the first time after bleeding the fuel system, or if the engine has run out of fuel, air pockets in the fuel system may prevent the engine from starting correctly. The procedure for priming the fuel system and removing the air pockets is as follows.


- 1 Locate the fuel priming pump on the fuel prefilter unit located on the left hand side of the vehicle above the fuel tank, as shown above right.
- 2 Alternatively, press and depress the priming button on the top to the pump/prefilter unit (A), as indicated, until it becomes difficult/stiff to operate (this may take several minutes).
- 3 Crank the engine until the engine fires. The maximum cranking time should not exceed 15 seconds or damage to the fuel pump may occur. It may be necessary to repeat step two. Wait at least a minute for the battery to recover before re cranking the engine.

THROTTLE SETTINGS

Iveco - Standard Power



John Deere - Standard Power



Copyright and rights are the property of Johnston Sweepers Ltd.

SET UP

Raise the body, operate the actuator to ensure that it is in the minimum speed position (L).

- 1 Check that the cable (C) is not under tension and that the arm (A) on the injector pump is resting against the engine idle adjuster screw. If not, loosen the screw in the cable nipple (B) to allow a little slack in the cable (C).
- 2 The following adjustments should be made with the fan outlet safety flap closed and a plate (suitably secured with clamp) completely blanking the fan inlet. Start auxiliary engine and allow to warm up.
- 3 Set throttle to idle. Check engine idle speed as shown in the table below. Adjust if necessary by way of the idle adjuster screw to give a smooth tickover.
- 4 Start engine. Actuate throttle control in cab to give maximum engine speed (H). Measure engine speed with tachometer and measure the off load speed as shown in the following table. At this speed setting ensure there is 0.25 - 0.5mm clearance between the arm and the maximum throttle screw.
- 5 Stop the auxiliary engine.
- 6 Remove fan inlet blanking plate before lowering the body.



Do not attempt to increase the 'off load' or 'flight speed' of the engine/fan impeller as these are safety critical items and have been preset at the factory

THROTTLE SETTINGS

These engines have their own ECU and the speeds are preset and can only be checked.


- 1 Raise the body.
- 2 With the fan safety flap closed and a plate (suitably secured with clamps) completely blanking the fan inlet.
- 3 Start the engine and allow to warm up.
- 4 Check the tickover speed and the maximum flight speeds. If these are incorrect, they must be reset by an authorised distributor.
- 5 **NOTE** : Remove the fan inlet blanking plate before lowering the body.

ENGINE TYPE	JOHNSTON PART NO.	IDLE SPEED Rev./Min.	MAXIMUM FLIGHT SPEED (Off Load) Rev./Min.
Iveco Stage 3a SP	283850-24	800	2200
Iveco Stage 3a HP	283805-24	800	2000
John Deere Tier 3 SP	283845-12	850	2200
John Deere Tier 3 HP	283791-12	800	2000

AUXILIARY ENGINE - FLUID FLYWHEEL

The fluid flywheel transmits power from the engine to the gearbox. Its design allows for the minimum of maintenance, minimal mechanical wear and superior longevity to the remainder of the transmission system. With the correct attention it should last the life of the sweeper.

- (A) Flywheel with side cover (C) removed.
- (B) Flywheel filler/inspection port visible through side cover sight hole.
- (C) Flywheel side cover.
- (D) Step-up gearbox.



**FLUID FLYWHEEL FILLING PORTS
(VIEWED WITH FAN CASE AND FAN REMOVED FOR CLARITY)**

MAINTENANCE

After the first 50 hours operation check the fluid level; this operation must be carried out with the unit cold. Repeat this check every 500 hours. The fluid flywheel is fitted with a fusible plug which melts at 198°C (recognised by four equi-spaced indentations round the hexagonal socket). Oil should be replaced after 4,000 hours operation.

FILLING INSTRUCTIONS

Rotate flywheel (A) until its filler port aligns with sight hole (B) in either of the two flywheel side covers (C), approximately 2 o'clock and 10 o'clock. Remove the side cover and spacers. Remove filler plug using a 5/16 AF allen key and fill with Johnston Fluid Flywheel Oil, Part No. 39673-5 until it reaches the level of the port. During filling, carefully rock the flywheel to ensure that no air pockets form below the oil level.

**DO NOT OVERFILL AS THIS WILL CAUSE THE UNIT TO OVERHEAT AND RAPID SEAL
DETERIORATION WILL OCCUR**

Replace the filler plug using thread sealant to ensure a good seal. Visually check for oil leaks and replace the flywheel cover.

DRAINING INSTRUCTIONS

Place a suitable drain tray under the flywheel housing if removing the Fan Case, remove filler plug and turn flywheel through 150° so that port is at lowest position.

If changing the oil use a propriety vacuum oil extractor/syringe after removing the filler plug.

Copyright and rights are the property of Johnston Sweepers Ltd.

HYDRAULIC OIL RESERVOIR

RENEWING THE RETURN FILTER

Unscrew cover (A) with a suitable spanner and lift out the cartridge element (B). Refit cartridge and screw on the cover, some force will be required to compress the carriage retaining spring.

SYSTEM DRAINING

The oil can be changed by removing the return filter A and the element and inserting standard gauge equipment for extraction of oil from engine sumps and tanks.


RENEWING THE SUCTION FILTER

The filter is best changed whilst the system is empty to prevent contaminated oil entering the suction port when the filter is removed. The filter is changed as follows.

Release the four retaining screws and remove the return filter assembly (C). There should be enough slack to remove the filter assembly with the 3 hydraulic hoses connected. The suction filter (E) can be reached by hand via the port and are removed by unscrewing. Similarly, the filter (F) option can be unscrewed and replaced. After fitting a new filter, replace the cover ensuring the 'O' ring is seated in its groove.

SYSTEM REFILLING

The system capacity dry is 90 litres. Refer to Chapter 6 of the Operator's Guide detailing the correct oil level in the reservoir.




95MA.003

Please refer to the Operator's Guide Section 6 for the Routine Maintenance Schedules.

The following covers items not included in the above guide.

HYDRAULIC OIL RETURN FILTER

The filter should be changed every 1000 hours, however there is an integral filter indicator on the side of the filter head and, should this indicate red whilst the suction fan is operating, i.e. body raised, then the filter is contaminated and requires changing at an earlier interval.



This should only be changed when the oil is cold, as the system could be pressurised. Leave for 60 seconds after stopping for any pressure to be disipated before removing the return filter.

HYDRAULIC OIL RESERVOIR

RENEWING THE RETURN FILTER

Unscrew cover (A) with a suitable spanner and lift out the cartridge element (B). Refit cartridge and screw on the cover, some force will be required to compress the carriage retaining spring.

SYSTEM DRAINING

The oil can be changed by removing the return filter A and the element and inserting standard gauge equipment for extraction of oil from engine sumps and tanks.


RENEWING THE SUCTION FILTER

The filter is best changed whilst the system is empty to prevent contaminated oil entering the suction port when the filter is removed. The filter is changed as follows.

Release the four retaining screws and remove the return filter assembly C. There should be enough slack to remove the filter assembly with the 3 hydraulic hoses connected. The suction filter (E) can be reached by hand via the port and are removed by unscrewing. Similarly, the filter (F option) can be unscrewed and replaced. After fitting a new filter, replace the cover ensuring the 'O' ring is seated in its groove.

SYSTEM REFILLING

The system capacity dry is 90 litres. Refer to Chapter 6 of the Operator's Guide detailing the correct oil level in the reservoir.





95MA.003-2


Copyright and rights are the property of Johnston Sweepers Ltd.

FILTER REGULATOR UNIT

Comprises of a combined air filter/pressure regulator. It is mounted in the systems locker.

 **Safety Precautions** 

The shut off valve must be used when servicing any item on the air system



The air filter unit incorporates a drain which automatically dumps accumulated water when the machine is shut down or when the air supply is isolated by the shut off valve (C). It can also be drained by pushing up the drain tube (B) that protrudes from the underside of the systems locker.

The pressure regulator (A) ensures the equipment is not over pressurised. It is factory set and sealed at 7.5 bar (108 psi).


A pressure switch (D) is fitted to illuminate the low air pressure warning lamp on the cab switch panel.

COWL SILENCER ASSEMBLY



The silencer chamber in the roof of the cowl should be cleaned periodically or the performance of the machine could be adversely affected.

Access to the chamber is gained by first removing the two screws (A). raise the top cover (B) on the hinge and secure on the prop (C).




95MA. 009

BODY ROOF DUCT INSPECTION PLATE/ACCESS DOOR OPTION



With mesh screens removed or lowered and the body raised (supported on its prop), clean the ducting in the top of the body using a broom and hosepipe. Access is gained by removing the top inspection plate, or hinged door (if option is fitted). Care should be taken not to get water into the fan case.



95MA. 010

PNEUMATIC CYLINDER MAINTENANCE

Periodically inspect the cylinder rods for damage, blemishes or build up of material such as tar, cement, paint etc. The rods can be cleaned with fine wire wool and/or spirit and should be kept clean to ensure long seal life.

HYDRAULIC CYLINDER MAINTENANCE

Observe the notes on damage etc. described under pneumatic cylinders, especially with regard to the wide sweep brush slewing cylinder on dual sweep machines and the channel brush lift cylinder. Avoid playing the water washdown hose over the body tip cylinder when in the fully raised condition.

CLEANING THE VEHICLE

With the advent of high pressure steam and washdown equipment, damage can be caused by playing this equipment onto the electrical control system, paintwork etc. and great care should be exercised when it is carried out.

Low pressure should always be used

This page is intentionally blank

Copyright and rights are the property of Johnston Sweepers Ltd.

Copyright and rights are the property of Johnston Sweepers Ltd.


Additional Information for VS Range

Introduction

The VS Range is the latest generation of chassis mounted road sweepers. The drive systems when sweeping are controlled by an on board microprocessor, which embodies a suite of software programs to suit specific applications and duties. This system allows the chassis to be driven normally from A to B and hydrostatically when in the work mode. The engine is controlled by the chassis ECU.

To guard against EMC interference, the controller casing is metallic encased and fully grounded to earth, and complies with EEC 89/336.

A typical circuit for the dual-mode hydromechanical propulsion system showing the various connections to external switches and sensors system is shown below.




- | | | | |
|-----|----------------------------------|-----|--|
| 1. | D-tec micro processor controller | 14. | Speed sensor - Datalogger |
| 2. | Connection plug | 15. | Existing Ignition |
| 3. | Programmer unit | 16. | Dual control change-over option |
| 4. | Hydrodrive Gearbox/Transmission | 17. | Primary foot pedal |
| 5. | Engage switch | 18. | Secondary foot pedal |
| 6. | Shifter cylinder | 19. | Throttle (switch or joystick)
3 position - spring centered |
| 7. | Pneumatic control valves | 20. | Hydrodrive engage/disengage |
| 8. | Air line | 21. | Direction control for hydrostatic drive
N = Neutral
F = Forward
R = Reverse |
| 9. | Datalogger | 22. | Chassis Tachometer |
| 10. | Electronic fuel pump | | |
| 11. | Transmission pump | | |
| 12. | Engine flywheel | | |
| 13. | Engine speed sensor | | |

With the advent of electronically controlled engines the D-Tec no longer controls the engine revs in work mode, it only controls the transmission.

The D-Tec controller module has five built-in status lamps in its upper surface, surrounded by a decal as shown below. These lamps provide indication of correct operation and assists in fault diagnosis if the need arises.

Top view of D-Tec Controller



Status Lamps

Power (green)

Lamp illuminates whenever the controller has electrical power applied to it.

Tacho (orange)

Lamp illuminates when the tachometer, using a Hall-Effect gear tooth sensor, correctly senses rotation whenever the engine runs above 300 rpm. If this lamp does not illuminate either the engine has stopped, the chassis gearbox is in neutral, or the sensor is positioned too far away from the tooth wheel in the case of the Hall-Effect sensors, or the electrical connections are disconnected in some way.

Throttle (yellow)

Lamp pulses progressively, increasing engine speed, increases pulse rate of lamp until 100% of throttle is achieved when lamp stays illuminated.

Reset (red)

Illuminates when there is a poor electrical connection, also illuminates when saving a setup parameter.

Status (yellow)

Lamp illuminates when 'work' mode is engaged.

Note: The D-Tec control unit is sealed and factory set, and cannot be adjusted. Inspection/testing of the unit can only be carried out with specialist equipment.

See Section 15 for D-Tec Set Up Procedure

Copyright and rights are the property of Johnston Sweepers Ltd.

REGULAR MAINTENANCE

It is impossible to over emphasise the importance of regular maintenance, inspection and running adjustments to maintain efficiency and obtain trouble free service from the machine.

Attention is drawn to the recommendation in the Chassis Handbook relating to the post delivery check over.

ENGINE MANAGEMENT ECU

Please note that the chassis manufacturers Engine Management System has been set in accordance with our requirements. If a malfunction of the ECU occurs and the component replaced then the parameters would require downloading and reset in the new component.

Failure to do this will cause the machine to malfunction.



Safety Precautions




- It is important that the Safety Precautions shown at the front of this chapter are observed when working on the VS machine.

TRANSMISSION PUMP OIL FILTER REPLACEMENT

This filter should be changed every 500 hours.

With the vehicle engine not running, remove the filter alongside the transmission pump.



M.0065

1. Transmission Pump Filter

Fit a new filter as quickly as possible to minimise the loss of any hydraulic oil. Ensure the correct filter is fitted, Part No 224-15, as this item is under pressure and 'Pattern Parts' may not be suitable.

Start engine and engage Hydrodrive. Allow system to tick over for a few minutes to purge air from the circuits.

CHAPTER

8

Hydraulic System

Table of Contents

Section	Page
Introduction	
General Description	8 : 2
Circuit Pressures	
Body Discharge System - VT & VS	8 : 2
Sweeping System - VT & VS	8 : 3
Supawash Option - VT & VS	8 : 3
Fan Drive System - VS Only	8 : 4
Hydraulic System	
Initial Operation	8 : 5
Systems Locker Valve Block	
Valve Identification	8 : 5
Modus Operandi	8 : 6
Circuit Diagrams	
Reservoir and System Services	8 : 8
Dual Sweep/Discharge System	8 : 10
Single Sweep/Discharge System	8 : 11
Fan Drive System - VS Only	8 : 12
Hydrodrive - VS Only	8 : 13
Powaboom	8 : 14
Secondary Pump Option Systems	8 : 15
Combivak Nozzle Option	8 : 16
Pump Services	8 : 17

GENERAL DESCRIPTION

The hydraulic system may be divided into four hydraulic circuits fed from a common hydraulic reservoir.

- 1 Sweep system and load discharge.
- 2 Options system for Supawash etc.
- 3 VS - Fan Drive
- 4 VS Only - Hydro drive system.

Hydraulic filtration is provided by suction filters within the hydraulic tank, together with replaceable type 'in line' return filter mounted externally on the upper face of the hydraulic tank.

CIRCUIT PRESSURES

Test points are provided on the hydraulic system to carry out pressure checks.

POINT NO.	FUNCTION	MACHINE TYPE
T1	Boost pressure, reverse pressure, antiskid	VS
T2	Pump control pressure	VS
T3	Boost pressure, forward pressure	VS
T4	Pump boost pressure	VS
T4B	Motor Pressure Control	VS
T5	Case pressure pump/motor	VS
T6	Coast pressure	VS
T7	Sweep system test point	VT & VS
T8	Fan drive system	VS
T9	Options system ie Supawash	VT & VS
GL	Body Lower	VT & VS

BODY DISCHARGE SYSTEM

Connect a suitable 250 bar gauge to Test Point T7 (see Valve Identification). Operate auxiliary engine at tick over, activate the body discharge system, press the rear door close button and read the pressure on T7. This should be 175 bar; adjust the discharge relief valve RV1 if necessary.

The system also has another relief valve of 80 bar on the body lower circuit to prevent damage to the body prop. To check pressure fit a 250 bar pressure gauge to Test Point GL. Operate the 'body down' button and record the pressure, adjust RV4 if necessary.

The door locking valve unit DL and sequence valve is preset and cannot be adjusted on the machine.

Tip Cylinder Descent Control (PC Flow Valve)

The flow restrictor is adjusted so the body descent empty is in excess of 15 seconds.

Note: Do not run the pressure test for more than 30 seconds.

SWEEPING SYSTEM

Connect a suitable 250 bar gauge to Test Point T7 (see Valve Identification).

To check main relief valve 225 bar, first remove solenoid valve plug Y on the dual machine (Z on single). Start auxiliary engine, increase engine speed to maximum. Run the auxiliary engine at 2000 rpm. Operate RH wide sweep brush and one channel brush, screw speed control in to give maximum brush speed. The pressure reading should be 225 bar. **NB** : Brushes will not rotate.

Adjust relief valve RV2 if necessary. **NB** : Do not run the pressure test for more than 30 seconds.

SUPAWASH OPTION

Connect a 250 bar gauge to Test Point T9 (see Hydraulics, Chapter 28).

It is necessary to remove hose 105 in Port MA of the valve and seal with a suitable plug - the hose will also need capping. Run auxiliary engine (VT)/engage hydrodrive (VS) and select Supawash and take a pressure reading, adjust the relief valve if necessary to give 220 bar. Turn off Supawash and stop engine. Reconnect pipework.

Note: Do not run the pressure test for more than 30 seconds.

FAN DRIVE SYSTEM

Fit a 250 bar minimum pressure gauge to test point T8.

Open rear door, open inlet flap.

Run the truck engine and engage hydrodrive, engage work mode and raise the engine speed to maximum 1700 rpm.

There should be a nominal reading of 18 bar which is the standby pressure. If this requires adjustment see chapter 22 VS section.

Operate the fan switch in enviro mode (middle position). The reading on the pressure gauge should be 150 bar. If this requires adjustment the relief valve is shown in Chapter 28 VS section. Remove the sealing cap and adjust allen screw to give required pressure. Refit sealing cap. Only carry out adjustment when fan switch is in the off position.

Operate the fan switch in the Boost Mode. The pressure reading should be 175 bar. If this requires adjustment, the relief valve is shown in Chapter 1.

HYDRAULIC SYSTEM INITIAL OPERATION


When the hydraulic system is first commissioned, or after changing a hydraulic hose on the hydraulic pumps on the body discharge circuit, it is necessary to purge any air from the system.

Firstly operate the electric discharge pump to open the rear door.

Then start the auxiliary engine on VT units, or engage the hydrodrive gearbox on VS units, and open and close the rear door three times to ensure all air is purged from the system.

Failure to carry out this procedure may cause the rear door locks to function incorrectly.

VALVE IDENTIFICATION



95MA. 036-3

Copyright and rights are the property of Johnston Sweepers Ltd.

MODUS OPERANDI

VT & VS Modular Series Hydraulic System- Modus Operandi for Base System

OPERATION	SOLENOIDS ENERGISED																		
	D	X	C	Y	Z	A1	A2	B1	B2	J	K	L	M	V	SP	YL	ZL	DL	
Operate WSB	√		√																
Extend WSB slew cylinder	√		√																
Retract WSB slew cylinder	√		√					√											
Operate LH CB motor		√			√														
Move LH CB out [Variabrush Option]		√			√														√
Move LH CB in [Variabrush Option]		√			√														
Lift LH CB - other systems inert (for 8 seconds)	√					√													
Lift LH CB with WSB active (A1 for 8 seconds)	X		X			√													
Operate RH CB motor		√		√															
Move RH CB out (while operating)		√		√															√
Move RH CB in (while operating)		√		√				√											
Lift RH CB - other systems inert (for 8 seconds)	√							√											
Lift RH CB with WSB & WP active (A2 for 8 seconds)	X		X					√											
Operate both channel brushes (Turbo & Hydro only)		√			√														√
Close rear door and lock (+ DL via limit switch)	√									√	√								√
Unlock rear door cylinder and open	√										√								
Extend body tip cylinder (raise)		√										√							
Retract body tip cylinder (lower)		√											√						
Extend propping cylinder (enable) [Option]	√																		
Retract propping cylinder (disable) [Option]	√																		
Powaboam (Option)	√																		√
Oil cool (motor) – VS Series only																			
Water pump (motor)																			
	+ CONTROLS ON PENDANT UNIT																		
	ALWAYS ACTIVE																		
	ALWAYS ACTIVE																		

KEY: √ = solenoid energised
 X = option of additional solenoid energised to fulfill function
 WSB = wide sweep brush rush motor
 CB = channel brush

Revision 03 Date 25/06/04 JGC

Copyright and rights are the property of Johnston Sweepers Ltd.

Copyright and rights are the property of Johnston Sweepers Ltd.

This page is intentionally blank


Reservoir and System Services - Diagram SH521a01



- 1 = SWEEP SYSTEM VALVE (return)
- 2 = RH/Single - CB (return)
- 3 = BRUSH SPEED CONTROL (return)
- 4 = WSB MOTOR (drain)
- 5 = WATER PUMP MOTOR (drain)
- 6 = SECONDARY PUMP RV (return - when specified)
- 7 = SUPAWASH OR FRONT BRUSH (return - when specified)

- A = SWEEP SYSTEM PUMP (feed)
- B = EMERGENCY DISCHARGE PUMP (feed)

NOTE: Additional return connections can also be used for other unspecified returns




HYDRAULIC SYSTEM
 Reservoir and System Services
 (Twin Engine Installation)

Johnston	VT Range	Reservoir & Systems Services	RD-060508	SH521a01	03
-----------------	-----------------	---	------------------	-----------------	-----------

ED22432

Copyright and rights are the property of Johnston Sweepers Ltd.


Reservoir and System Services - Diagram SH521b03



ECM 705284

Johnston	V/S Range	Series 2 System	JC-17/05/10	SH521b01	03
-----------------	------------------	------------------------	-------------	-----------------	----

Dual Sweep/Discharge System - Diagram SH522z01




GENERAL NOTES	REVISIONS	DATE	BY
UPFOLD	UPFOLD	22.12.2011	UPFOLD
REVISION	DESCRIPTION	DATE	BY
01	DUAL SWEEP HYDRAULIC CIRCUIT	22.12.2011	UPFOLD

PROJECT	RES/PROJ/REV	SCALE	SHEET	DOCU/REV	REVISION	DATE
Johnston SWEEPERS	C-D	1:1	1/1	SH522Z01	A	707373

Copyright and rights are the property of Johnston Sweepers Ltd.

Single Sweep/Discharge System - Diagram SH523z01




GENERAL SERVICES	RELIEF VALVES	RELIEF QUALITY	REVISED BY	DATE	REASON	DATE
			UPFOLD	22.12.2011	UPFOLD	22.12.2011

REVISIONS	DESCRIPTION	DATE	BY	SCALE	SHEET	DOCSHEET NUMBER	REVISION	DATE
1	175 BAR	1/1	A	1:1	1/1	SH523Z01	A	707373

GENERAL SERVICES	RELIEF VALVES	RELIEF QUALITY	REVISED BY	DATE	REASON	DATE
			UPFOLD	22.12.2011	UPFOLD	22.12.2011

REVISIONS	DESCRIPTION	DATE	BY	SCALE	SHEET	DOCSHEET NUMBER	REVISION	DATE
1	175 BAR	1/1	A	1:1	1/1	SH523Z01	A	707373

Fan Drive Diagram SH524z01




HYDRAULIC SYSTEM
Suction Fan Drive
(Single Engine Installation)

ED20226

Johnston	VS Range	Series 2 System	RD-040526	SH524z01	00
-----------------	-----------------	------------------------	------------------	-----------------	-----------

Hydrodrive Diagram SH525z01



TEST POINTS
 T1 = BOOST PRESSURE, R - POWER LIMITER, ANTI-SKID
 T2 = EDC OUTPUT SIGNAL
 T3 = BOOST PRESSURE, F - POWER LIMITER
 T4 = BOOST PRESSURE BEFORE FILTER
 T4B = DISPLACEMENT CONTROL
 T5 = CASE PRESSURE
 T6 = COAST CONTROL

FLOW IN MOTOR PORT A = FORWARD (F)
 FLOW IN MOTOR PORT B = REVERSE (R)
 FOR CONNECTIONS D.2 & 16 SEE SH121
 SW = PROVISION FOR BRAKE LAMP SWITCH (option)
 RL VALVE ENERGISED IN FORWARD MODE
 32° ADJUST AS NECESSARY FOR 30km/h MAX SPEED




Fan Bay

7. ANTI-SKID MODULE

HYDRAULIC SYSTEM
 Hydrodrive Transmission

ED20263	RD-040607	SH525z01	01
Johnston	VS Range	Series 2 System	

Powaboom - Diagram SH527z01






HYDRAULIC SYSTEM
Powaboom Wanderhose

	V Range	Series 2 System	RD-24/09/07	ED23643
			SH527z01	02

Copyright and rights are the property of Johnston Sweepers Ltd.


Type 'D' Secondary Pump Option Systems - Diagram SH528a04



HYDRAULIC SYSTEM
(secondary pump option systems)

	Johnston	<i>VT/VS Range</i>	Mk2 Secondary Pump Option	RD-22/02/07	SH528a04	01
				ED23184		




Combivak Nozzle Option - Diagram SH529z01



GENERAL TOLERANCES	VELDING TOLERANCES	WELD QUALITY	ORDER BY	DATE	RELEASED BY	DATE
			UPFOLD	22.12.2011	UPFOLD	22.12.2011
 Johnston SWEEPS			TITLE (SUPERMARKET TITLE) COMBIVAK NOZZLE			
COMPANY: Johnston Sweeps Division of Cooper Industries © 2012 Cooper Industries Business Limited			PROJECT HYDRAULIC CIRCUIT			
RESPONSIBLE ENGINEER/TITLE	DOC TYPE	REVISION	SCALE	SHEET	DOOR/FOLDER NUMBER	REVISION
C-D	ACD	01	1:1	1/1	SH529Z01	A
			ANGLE			EN
						707373

Copyright and rights are the property of Johnston Sweepers Ltd.

Pump Services - Diagram SH531a01





Single Pump System with Additional Emergency Discharge Pump

Tandem Pump System with Additional Emergency Discharge Pump

HYDRAULIC SYSTEM
Pump Services
 (Twin Engine Installation)

ED14918	MC-030709	SH531a01	00
	Johnston 295/296 Modular Series 2 System		

Pump Services - Diagram SH531b01



Single Pump System with Additional Emergency Discharge Pump

Dual Pump System with Additional Emergency Discharge Pump


HYDRAULIC SYSTEM
Pump Services
 (Single Engine Installation)

	VS Range	Series 2 System	RD-040526	SH531b01	00
			ED20226		


Copyright and rights are the property of Johnston Sweepers Ltd.

Wide Sweep Brush Speed Control - Option - Diagram SH532z01

Copyright and rights are the property of Johnston Sweepers Ltd.



<p>IT IS AN IMPROVEMENT OF THESE PATENTS AND DESIGN PATENTS TO ANY OTHER COPYRIGHT FROM JOHNSTON SWEEPERS LIMITED.</p>	<p>WIDE SWEEP BRUSH SPEED CONTROL HYDRAULIC CIRCUIT</p>	<p>PH. 0226643</p>	<p>REV. 01</p>
		<p>MODEL Y RANGE</p>	<p>REV. 00</p>
<p>Johnston SWEEPERS LIMITED CURTIS ROAD, LUDLOW, SHREWSBURY, UK. BAC 15F</p>		<p>SH532z01</p>	

Low Pressure Water Pump Shut Off - Option - Diagram SH534z01


Copyright and rights are the property of Johnston Sweepers Ltd.

CHAPTER

9

Electrical System**Table of Contents**

Section	Page
Introduction	
General Description	9 : 2
System Description	9 : 2
Component Identification	
Systems Locker	9 : 3
Relay Box	9 : 3
Relay/Diode/Fuse and Connector Refs.	9 : 4
Powapak Management Boxes	9 : 13
Component Codes and Descriptions	
Component Index and Identifier	9 : 15
Circuit Diagrams	
Circuit Diagrams	9 : 17

NB - The electrical system uses Type B switches.

GENERAL DESCRIPTION


The system is integrated with that of the chassis in that it shares its battery and power source. The auxiliary engine is equipped with a second alternator to supplement power generation. The system activates all operational functions of the machine except channel brush speed regulation.

SYSTEM DESCRIPTION

The electrical system circuit diagrams are sub divided into modularised sub circuits and are identified by an eight digit code, i.e. SE511Z01. The first five digits identify the machine and a particular control feature, the last three digits identify variation and design status of the particular control feature. When the sixth digit is a 'Z', then there is only one design variation, though there could be other variations identified by the seventh and eighth digits.

To assist fault finding and troubleshooting, the solenoids have an LED in the electrical connection plug which illuminate when power is achieved.


The electrical system is protected by various fuses - See Chapter 2.



The main feed from the battery to the electrical system is protected by a circuit breaker (B) which is mounted in the systems wafer.

The button (B) will pop out when activated and is 'pushed in' to reset when the fault has been cleared.


The electrical system uses Type B switches, the Type A switch is shown below for reference only.



95MA.037

COMPONENT IDENTIFICATION


SYSTEMS LOCKER



95MA.036-4

RELAY BOX

Dual sweep box shown



95MA.025-3

Copyright and rights are the property of Johnston Sweepers Ltd.

Relays

Item	Description / Function	VT	VS	Location
R1	Main power relay Fuses 3-8	√	√	Relay Box
R2 to R4	Not fitted			N/A
R5	Sweeping hours Signal for wizard monitor Active with right hand nozzle	√	√	Relay Box
R6	Discharge control Pendant power supply	√	√	Relay Box
R7	Supawash control Active with full water tank switching negative between hydraulic valve and low water level lamp	√	√	Relay Box
R8	Hydrodrive Select Interlock Active with Hand brake and Clutch Switch	X	√	D-Tec Box
R10	Suction Fan Control Active With Reverse/Ergo Selected	X	√	Fan Pack Management Box
R11	Transmission Control Active with Forward Selected - Interrupted with Air Suspension Active	X	√	Fan Pack Management Box
R12	Handbrake signal discharge select (Only ever active if a positive signal is used)	√	√	Relay Box
R20	Auxiliary engine ECU ignition Interlock relay for timer relay 7	√	X	E/Man Box
R21	Auxiliary engine ECU ignition Interlock relay for oil pressure	√	X	E/Man Box
R22	Auxiliary engine ECU ignition Interlock relay for water temperature	√	X	E/Man Box
K1	Auxiliary engine ignition Active with auxiliary ignition switch - signals ECU	√	X	E/Man Box
P.C.B	PCB Pendant control Active with Pendant control Buttons	√	√	Relay Box
FB	Front beacon Active with beacon switch	√	√	Relay Box
PR2	Provides power to fuses 3-6 Active with auxiliary ignition	√	√	Relay Box
PR3	Provides power to sweep gear when Inert Active with Program button or Reverse	√	√	Relay Box
PSM 1	PTO 1 In PSM - Fixed Engine Speed Active with Air Suspension	X	√	D-Tec Box
PSM 2	WLI Lamp Control Active with Air Suspension - Switches Off Lamp	X	√	D-Tec Box
PSM 3	Hydrostatic Road Speed Reduction Active with Air Suspension - Switches -Ve to R11 Transmission Control	X	√	D-Tec Box
PSM 4	PTO 3 - Feed Back Active with Master Switch - Sends -Ve to PTO 3 - Feed Back	X	√	D-Tec Box

Copyright and rights are the property of Johnston Sweepers Ltd.

Relays (continued)

RA	Auxiliary engine alternator charge lamp Located in ignition switch	√	X	E/Man Box
RC	Positive cranking Provides a continuous earth to relay RS while auxiliary engine is cranking	√	X	E/Man Box
RFh	Auxiliary engine fuel heater Controlled by ECU	√	X	E/Man Box
RN	Front brush control	√	√	Relay Box
RP	Autoprop control Active with hopper raise switch deactivating valve v	√	√	Relay Box
RS	Power relay for cranking Active with crank button	√	X	E/Man Box
RT1	External throttle Active for speed down – switching negative	√	X	Subframe
RT2	External throttle Active for speed up – switching negative	√	X	Subframe
RTD 1	Accelerator Pedal Change Over Active with Master Switch	X	√	D-Tec Box
RTD 2	Accelerator Pedal Change Over Active with Master Switch	X	√	D-Tec Box
RW	Simultaneous sweep Active with LH CB – de-activates Y and activates SP	√	√	Relay Box
RX	Work Mode Active with Master Switch	X	√	D-Tec Box
RY	Neutral Simulation Active with Work Mode	X	√	D-Tec Box
RZ	Anti-Crank / Alternator Active with Ignition Only	√	X	E/Man Box J/D Only

Timer Relays

T1	W/Sweep Powascrub W/Sweep rotation delayed for duration of timer Powascrub active for duration of timer Set to 0.5 sec - activated by turning WSB on	√	√	Relay Box
T2	L/H Channel brush auto out Active for duration of timer Set to 6.0 sec - activated by turning L/H C/Brush on	√	√	Relay Box
T3	L/H Channel brush auto in Active for duration of timer Set to 8.0 sec - activated by turning L/H C/Brush off	√	√	Relay Box
T4	R/H Channel brush auto out Active for duration of timer Set to 6.0 sec - activated by turning R/H C/Brush on	√	√	Relay Box
T5	R/H Channel brush auto in Active for duration of timer Set to 8.0 sec - activated by turning R/H C/Brush off	√	√	Relay Box
T6	Anti-Crank Set to 0.5 sec - activated on releasing the Crank switch	√	X	E/Man Box
T7	Auxiliary engine ECU ignition Set to 8.0 sec - activated when pressing the Crank switch	√	X	E/Man Box

Copyright and rights are the property of Johnston Sweepers Ltd.

Resistors

Ident.	Description / Function	VT	VS	Location
RS1	Stage 3 Engine CAN 120R	√	X	E/Man Box
RS2	Simulates Accelerator Pedal 100R	√	X	E/Man Box
RS3	Simulates Accelerator Pedal 1k0	√	X	E/Man Box
RS4	Simulates Accelerator Pedal 910R	√	X	E/Man Box
RS5	Simulates Vehicle Road Speed 3k3	√	X	E/Man Box
RT	Simulates - Heatstart Relay	√	X	Engine Loom
???	Simulates Accelerator Pedal 300R	X	√	D-Tec Box
???	Simulates Accelerator Pedal 2k2	X	√	D-Tec Box

Diodes

Ident.	Description / Function	Location
D1	Operation – Valve D	Relay Box
D2	Operation – Valve D	Relay Box
D3	Wide sweep brush slew	Relay Box
D4	Wide sweep brush slew	Relay Box
D5	Operation – Valve X	Relay Box
D6	Operation – Valve X	Relay Box
D7	Nozzle water control	Relay Box
D8	Nozzle water control	Relay Box
D9	Park brake signal	Relay Box
D10	Operation – Valve K	Relay Box
D11	Program button isolate	Relay Box
D12	Operation – Valve D	Relay Box
D13	Operation – Valve D	Relay Box
D14	D.A.W. Operation during load discharge	Relay Box
D15	Earth for Powaboom	Relay Box
D16 to D18	Vacant	N/A
D19	Operation – Valve M	Relay Box
D21	Reverse signal isolation	Relay Box
D24	Varagap isolation	Relay Box
D25	Varagap isolation	Relay Box
D26	Auxiliary engine crank	E/Man Box

Diodes (continued)

D27	Program isolation	Relay Box
D28	Program isolation	Relay Box
D29	Timer relay isolation	Relay Box
D30	Timer relay isolation	Relay Box
D31	Timer relay isolation	Relay Box
D32	Timer relay isolation	Relay Box
D40	Auxiliary engine anti-crank	E/Man Box
D41	Auxiliary engine anti-crank	E/Man Box
D42	Auxiliary engine alternator charge lamp isolation	E/Man Box
DB1	Hydraulic oil level switch isolation	Relay Box
DB2	Rear door closed switch isolation	Relay Box
DB3	Low air pressure switch isolation	Relay Box
DB4	Auxiliary engine ignition isolation	Relay Box
DB5	Hopper raised switch isolation	Relay Box
DB6	Low water level switch isolation	Relay Box

Fuses

Ident.	Description / Function	Rating (A)	Location
MCB	Main Circuit Breaker	50amp@12V 30amp@24V	Systems Locker
F1	Rear Beacons	15	Relay Box
F2	Front Beacons / AWB	15	Relay Box
F3	Work lights / AWL	15	Relay Box
F4	Channel brush / Nozzle / Flaps	15	Relay Box
F5	Wide sweep brush / Supawash	15	Relay Box
F6	Discharge select / Pendant	15	Relay Box
F7	Auto lube / Cowl Work lamp / Audible Buzzer / Instrument Panel	15	Relay Box
F8	Auxiliary Ignition Supply / Switch Location LED's	15	Relay Box
F20	Spare		
F21	Spare		
FE1	Battery +Ve ECU	30	E/Man Box
FE2	Battery + Ve Diagnosis Plug	5	E/Man Box
FE3	Battery + Ve Power Supply to Relay K1	5	E/Man Box
FE4	Battery + Ve Power Supply to Relay RFh	15	E/Man Box
FE5	Battery + Ve Power Supply to Relay RS	15	E/Man Box
FE6	Spare		E/Man Box

Copyright and rights are the property of Johnston Sweepers Ltd.

Connectors P01 - P60

Ident.	No.Ways	Location	Harness Ref. (Female)	Harness Ref. (Male)
P01	17	Relay Box	283399 / 283502	283260
P02	17	Relay Box	283399 / 283502	283260
P03	17	Relay Box	283399 / 283502	283260
P04	17	Relay Box	283399	283265
P05	17	Relay Box	283399 / 283502	282022
P06	17	Relay Box	283399 / 283502	282022
P07	17	Relay Box	283399	282023
P08	9	Relay Box	283399 / 283502	282199
P09	17	Relay Box	283399 / 283502	283186
P10	3	Switch Panel	809308/809440	809312
P11	5	Switch Panel	950312	282053
P12	17	Relay Box	283399 / 283502	282022
P14	17	Switch Panel	950312	282020
P15	17	Switch Panel	950312	282022
P16	17	Switch Panel	950312	282022
P17	17	Switch Panel	950312	282023
P18	9	Switch Panel	950312	283853
P19	7	Switch Panel	809441	809440
P20	7	Chassis Cab	809441	809442
P21	5	Switch Panel	950312	283233//809308/809440
P21-A	5	Switch Panel	809308/809440	Not used
P22	17	Switch Panel	950312	282022
P23	3	Switch Panel	809313	809308
P24	11	Switch Panel	809309	809308
P25	13	Chassis Cab	809309	809310

Connectors P01 to P60 (continued)

Ident.	No.Ways	Location	Harness Ref. (Female)	Harness Ref. (Male)
P26	2	Chassis Cab	809309	809311
P28	7	Relay box	283399/283502	283440-1/283440/2
P26 to P30	Not used			
P31	8	Subframe	282062	282063
P32	8	Powaboom Pend.	282063	282061
P33 to p47	Not used			
P48	48	Systems locker	283260	282063
P49 to p50	Not used			
P51	9	Switch Panel	950312	283186
P52 to P53	Not used			
P54	8	Fr. Brush Control	Not yet issued	Not yet issued
P55	8	Fr. Brush Control	Not yet issued	Not yet issued
P56 to P60	Not used			

Connectors Axx - Zxx

Ident.	No.Ways	Location	Harness Ref. (Female)	Harness Ref. (Male)
AL	2		Autoloc	283261/809311/809442
AL-A	2		Not used	809357
AL-D	2		809357	Not used
AL-E	2		809357	Not used
AWL	2	Subframe	293774	283235
BEAC	5	Chassis Cab		283186
BL	8	Subframe	283261	283262
C2	3	Chassis Cab	809313	809206
CAM	5	Chassis Cab		283186
CWL	2	Body	282456	283262
CV	4	Subframe	283566	283260
DAW	2	Power Pack	30/184	283263
DD1	17	Relay Box	283398	283399
DG1	2	Man/Box	283857	283857
DL	2	Subframe	283261	281907
DR	3	Subframe	283261	282187
DS1	17	Relay Box	283399 / 283502	283501
DS2	13	Relay Box	283399 / 283502	283501
DT	33	DTec Box		
DT01	13	DTec Box		
DX1	17	Switch Panel		
DX2	17	DTec Box		
EC	12	Edge Cutter	809442	809444
EDP	1	Subframe	281938	283261

Connectors Axx to Zxx

Ident.	No.Ways	Location	Harness Ref. (Female)	Harness Ref. (Male)
ESC(A)	4	Subframe	282020 (282060 ext. throttle)	282020
ESC(B)	4	Subframe	282020	282020 (282060 ext. throttle)
FB1	2	Relay Box	Not yet issued	Not yet issued
FLS	2	Fuel Tank	281967	283263
GP	23 (VS)	Power Pack	282049 – VS	282050 – VS
HOL	2	Hydraulic Tank	48/328	283263
HR	1	Body	283261	Hopper Raised Switch
L-BEAC	2	Body	282793	283262
LH-AWL	2	Body	293774	Worklight
LRML	2	Body	Marker Light	283262
LS	2	Body	282186	283262
LW	2	Body	48/238	283261
ML	2	Subframe	807613 – DAF LF55 807617 – Volvo 807718 – Iveco 807908 – MAN 807586 – Scania	283261
NP	2	Subframe	<i>Not used</i>	283261
OPS	2	Power Pack	Fitted on Iveco stage 3 Engine.	283851 Iveco Stage 3 .
PB	3	Subframe	282065	282062, 282160, 282161
PC	3	Subframe	282062, 282160, 282161	283261
PCI	17	Cab	283186	283222 – Daf 283223 – Iveco 283224 – Man 283227 – Renault 283429 – Mercedes 809760 -- Scania
PCB1	10	Relay box	283399/283502	283646-1
PCB2	8	Relay box	283399/283502	283646-1
PE	31	Power Pack	283851 Iveco Stage 3 282050 – Hydrostatic	283852 Iveco Stage 3 282135 – Hydrostatic

Copyright and rights are the property of Johnston Sweepers Ltd.

Connectors Axx to Zxx (continued)



Ident.	No.Ways	Location	Harness Ref. (Female)	Harness Ref. (Male)
PP	17	Power Pack	282020	282050 – Hydrostatic 283851 Iveco Stage 3
PS	4	Front Brush/ Edge Cutter	809205	809204/809442
PT	6	Power Pack	283263	283264
PZ	29	Systems Locker	283265	283264
R-BEAC	2	Body	282793	283262
RH-AWL	2	Body	293774	Worklight
RRML	2	Body	Marker Light	283262
RT1	2	Channel Brush	282508	282053
RT2	2	Channel Brush	282508	282053
SC	12	Front Brush	809310	809204
SF	12	Subframe	283260	283261
SV	2	Subframe	282069	283260
WD	2	Subframe	282456	283265
WS	2	Subframe	282456	283260
VB	12	Front Brush	809314	809204

Rev. WD 234 issue 01

Copyright and rights are the property of Johnston Sweepers Ltd.



Powapack Management Box

John Deere Tier 3 Standard Power





95EC.004-8M

John Deere Tier 3 High Power





95EC.004-9M

Iveco Stage 3a Standard Power



95EC.006-13M



Iveco Stage 3a High Power



95EC.005-8M


Powapak Management Box

Hydrostatic - VS



95EC.007-4M

D-Tec Box in Cab - VS




95EC. 008-2

Copyright and rights are the property of Johnston Sweepers Ltd.

Type B Switches - Electrical Components Diagram - SE550z11

Copyright and rights are the property of Johnston Sweepers Ltd.




Type B Switches - Electrical Components Diagram - SE550z12


CABLE IDENTIFICATION

WIRE COLOUR CODE




CODE	COLOUR	CODE	COLOUR	CODE	COLOUR	CODE	COLOUR
B	BLACK	T	ORANGE	U	BLUE	W	WHITE
N	BROWN	Y	YELLOW	P	PURPLE	K	PINK
R	RED	G	GREEN	S	SLATE	LG	L GREEN



- 16-R/W- ELECTRICAL CABLE - 0.50mm² (16/0.20)
- R/W - OR -32-R/W- ELECTRICAL CABLE - 1.00mm² (32/0.20)
- R/W - OR -28-R/W- ELECTRICAL CABLE - 2.00mm² (28/0.30)
- R/W - OR -44-R/W- ELECTRICAL CABLE - 3.00mm² (44/0.30)
- R/W - OR -65-R/W- ELECTRICAL CABLE - 4.50mm² (65/0.30)





- SHIELDED ELECTRICAL CABLE
- MULTI-CORE ELECTRICAL CABLE




MAIN FUNCTION SWITCHES (10-8 FUNCTION, 9-7 LOCATION)

OTHER FUNCTION SWITCHES




CONTROL RELAYS & SWITCHES




System Map Mk II Systems Wafer Black Discharge Pendant Diagram - SE551z04


Copyright and rights are the property of Johnston Sweepers Ltd.




Switch Panel Diagram Stage 3a Engines - SE552z04




IVECO S3A HIGH POWER



HYDROSTATIC



JOHN DEERE TIER3 HIGH POWER




IVECO STAGE3 STANDARD POWER
JOHN DEERE TIER3 STANDARD POWER

*DS SWITCH ONLY FITTED ON LEGACY PANELS


Copyright and rights are the property of Johnston Sweepers Ltd.

Diode Pack Diagram - SE553z02



JOHNSTON SWEEPERS LIMITED
 CURTIS ROAD, DORRIS, SOMERSET, U.K. BA4 1JF
 TEL: 01458 821188
 FAX: 01458 821189
 E-MAIL: JOHNSTON@JSL.COM
 WWW: WWW.JSL.COM
 DRAWING NO: SE553z02
 REV: 00
 PROJECT: VT VS RANGE
 PART NO: SE553z02
 REVISION: 00


Relay Panel Diagram - SE553z04




Copyright and rights are the property of Johnston Sweepers Ltd.

Fuse / Main Relay Diagram - SE554z02

Copyright and rights are the property of Johnston Sweepers Ltd.



Program & Discharge Diagram Type B Switches - SE555z03




<p>Johnston SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK. RH4 1YF</p>		<p>IF AN IMPROVEMENT OF THIS DRAWING IS REQUIRED, PLEASE CONTACT US BY TELEPHONE OR E-MAIL. WE WILL BE GLAD TO ASSIST YOU WITH ANY TECHNICAL INFORMATION.</p>	<p>ED22842 VT VS RANGE SE555z03</p>
<p>PROGRAM/DISCHARGE</p>		<p>REVISION</p>	<p>00</p>

Copyright and rights are the property of Johnston Sweepers Ltd.

Black Discharge Control Pendant - SE556z03

Copyright and rights are the property of Johnston Sweepers Ltd.



DISCHARGE CONTROL
BLACK PENDANT

SE556z03


01

JOHNSTON SWEEPERS LIMITED
COURT ROAD, DORRING, SURREY, UK, RH4 1JF

THE COMPANY'S PROPERTY
NO COPY OR COMMUNICATION
TO BE MADE WITHOUT WRITTEN
AUTHORITY

US: 0702259
UK: 01438 85704/09
VT VS RANGE

Beacons Diagram Type B Switches - SE557z03



REV. NO.	REV. DATE	REV. BY	REV. DESCRIPTION
01	05/11/08	SAW	VT & VS RANGE
02			SE557Z03


BEACONS

THE UNIVERSITY OF
 JOHNSTON SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK. RH4 1XF

Copyright and rights are the property of Johnston Sweepers Ltd.


Worklamps & Marker Lights Diagram Type B Switches - SE558z03

Copyright and rights are the property of Johnston Sweepers Ltd.



 Johnston SWEEPERS LIMITED <small>CURTIS ROAD, DORING, SURREY, UK. RH4 1YF</small>	IT IS AN IMPROVEMENT OF THE ORIGINAL DESIGN AND IN THIS DRAWING AND DESIGN IT IS THE PROPERTY OF JOHNSTON SWEEPERS LIMITED. JOHNSTON SWEEPERS LIMITED.	TITLE WORKLAMPS AND MARKER LIGHTS	DRAWING NO. SE558z03	REV. NO. 00
	PROJECT NO. VT VS RANGE	DATE 18/07/10	DRAWN BY SE558z03	CHECKED BY 00

Instrument Panel Diagram - SE559z02




CURTIS ROAD, DORKING, SURREY, UK, RH4 1XF

Copyright and rights are the property of Johnston Sweepers Ltd.


Channel Brush Single Sweep Diagram Type B Switches - SE561z03

Copyright and rights are the property of Johnston Sweepers Ltd.



REV. NO.	REV. DATE	REV. DESCRIPTION
00	06/11/06	SE561z03
CHANNEL BRUSH SINGLE		
 JOHNSTON SWEEPERS LIMITED GURTS ROAD, DORKING, SURREY, UK, RH4 1YF		
TITLE: CHANNEL BRUSH SINGLE PROJECT: VT VS RANGE DRAWING NO: SE561z03		

Channel Brush Dual Sweep Diagram Type B Switches - SE562z03




<p>Johnston SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK, RH4 1YF</p>	<p>IT IS AN INSTRUMENT OF THE COMPANY AND ALL RIGHTS RESERVED IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING OR BY ANY INFORMATION STORAGE AND RETRIEVAL SYSTEM, WITHOUT THE WRITTEN CONSENT FROM JOHNSTON SWEEPERS LIMITED.</p>	<p>ED22842 REV. 01 REV. 02 REV. 03 REV. 04 REV. 05 REV. 06 REV. 07 REV. 08 REV. 09 REV. 10 REV. 11/06</p>
	<p>CHANNEL BRUSH DUAL</p>	<p>SE562z03</p>


Copyright and rights are the property of Johnston Sweepers Ltd.

Nozzle Single Sweep Diagram Type B Switches - SE563z03

Copyright and rights are the property of Johnston Sweepers Ltd.



Nozzle Dual Sweep Diagram Type B Switches - SE564z03



JOHNSTON SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK. RH4 1YF
 JOHNSTON SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK. RH4 1YF

Johnston
 SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK. RH4 1YF

FILE NO. D22842
 REV. NO. 01
 PROJECT: VT VS RANGE
 DRAWING NO. SE564z03
 REVISION NO. 00


TITLE: NOZZLE DUAL

IT IS THE RESPONSIBILITY OF THE COMPANY'S COPYRIGHT HOLDER TO COPY OR TRANSMIT THIS DRAWING WITHOUT WRITING PERMISSION FROM JOHNSTON SWEEPERS LIMITED.


Copyright and rights are the property of Johnston Sweepers Ltd.

Wide Sweep Single Diagram Type B Switches - SE565z03

Copyright and rights are the property of Johnston Sweepers Ltd.



Wide Sweep Dual Diagram Type B Switches - SE566z03



Johnston SWEEPERS LIMITED
CURTIS ROAD, DORKING, SURREY, UK. RH4 1XF

REF: ED22842
POWER: VT VS RANGE
REV: 06/11/08

WIDE SWEEP BRUSH DUAL


THIS IS AN UNREGISTERED DESIGN OF THE COMPANY'S COPYRIGHT TO COPY OR COMMUNICATE IN ANY MANNER WITHOUT THE WRITTEN PERMISSION OF JOHNSTON SWEEPERS LIMITED.

SE566Z03

REVISION: 00


Copyright and rights are the property of Johnston Sweepers Ltd.

Intake Flaps Diagram - SE567z02



<p>JOHNSTON SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK, RH4 1XF</p>		<p>TITLE: INTAKE FLAPS</p> <p>REV: 01/06/11</p> <p>REV: 02/06/11</p> <p>REV: 03/06/11</p> <p>REV: 04/06/11</p> <p>REV: 05/06/11</p> <p>REV: 06/06/11</p> <p>REV: 07/06/11</p> <p>REV: 08/06/11</p> <p>REV: 09/06/11</p> <p>REV: 10/06/11</p> <p>REV: 11/06/11</p> <p>REV: 12/06/11</p> <p>REV: 13/06/11</p> <p>REV: 14/06/11</p> <p>REV: 15/06/11</p> <p>REV: 16/06/11</p> <p>REV: 17/06/11</p> <p>REV: 18/06/11</p> <p>REV: 19/06/11</p> <p>REV: 20/06/11</p> <p>REV: 21/06/11</p> <p>REV: 22/06/11</p> <p>REV: 23/06/11</p> <p>REV: 24/06/11</p> <p>REV: 25/06/11</p> <p>REV: 26/06/11</p> <p>REV: 27/06/11</p> <p>REV: 28/06/11</p> <p>REV: 29/06/11</p> <p>REV: 30/06/11</p> <p>REV: 31/06/11</p> <p>REV: 32/06/11</p> <p>REV: 33/06/11</p> <p>REV: 34/06/11</p> <p>REV: 35/06/11</p> <p>REV: 36/06/11</p> <p>REV: 37/06/11</p> <p>REV: 38/06/11</p> <p>REV: 39/06/11</p> <p>REV: 40/06/11</p> <p>REV: 41/06/11</p> <p>REV: 42/06/11</p> <p>REV: 43/06/11</p> <p>REV: 44/06/11</p> <p>REV: 45/06/11</p> <p>REV: 46/06/11</p> <p>REV: 47/06/11</p> <p>REV: 48/06/11</p> <p>REV: 49/06/11</p> <p>REV: 50/06/11</p> <p>REV: 51/06/11</p> <p>REV: 52/06/11</p> <p>REV: 53/06/11</p> <p>REV: 54/06/11</p> <p>REV: 55/06/11</p> <p>REV: 56/06/11</p> <p>REV: 57/06/11</p> <p>REV: 58/06/11</p> <p>REV: 59/06/11</p> <p>REV: 60/06/11</p> <p>REV: 61/06/11</p> <p>REV: 62/06/11</p> <p>REV: 63/06/11</p> <p>REV: 64/06/11</p> <p>REV: 65/06/11</p> <p>REV: 66/06/11</p> <p>REV: 67/06/11</p> <p>REV: 68/06/11</p> <p>REV: 69/06/11</p> <p>REV: 70/06/11</p> <p>REV: 71/06/11</p> <p>REV: 72/06/11</p> <p>REV: 73/06/11</p> <p>REV: 74/06/11</p> <p>REV: 75/06/11</p> <p>REV: 76/06/11</p> <p>REV: 77/06/11</p> <p>REV: 78/06/11</p> <p>REV: 79/06/11</p> <p>REV: 80/06/11</p> <p>REV: 81/06/11</p> <p>REV: 82/06/11</p> <p>REV: 83/06/11</p> <p>REV: 84/06/11</p> <p>REV: 85/06/11</p> <p>REV: 86/06/11</p> <p>REV: 87/06/11</p> <p>REV: 88/06/11</p> <p>REV: 89/06/11</p> <p>REV: 90/06/11</p> <p>REV: 91/06/11</p> <p>REV: 92/06/11</p> <p>REV: 93/06/11</p> <p>REV: 94/06/11</p> <p>REV: 95/06/11</p> <p>REV: 96/06/11</p> <p>REV: 97/06/11</p> <p>REV: 98/06/11</p> <p>REV: 99/06/11</p> <p>REV: 100/06/11</p>		<p>REV: 01/06/11</p> <p>REV: 02/06/11</p> <p>REV: 03/06/11</p> <p>REV: 04/06/11</p> <p>REV: 05/06/11</p> <p>REV: 06/06/11</p> <p>REV: 07/06/11</p> <p>REV: 08/06/11</p> <p>REV: 09/06/11</p> <p>REV: 10/06/11</p> <p>REV: 11/06/11</p> <p>REV: 12/06/11</p> <p>REV: 13/06/11</p> <p>REV: 14/06/11</p> <p>REV: 15/06/11</p> <p>REV: 16/06/11</p> <p>REV: 17/06/11</p> <p>REV: 18/06/11</p> <p>REV: 19/06/11</p> <p>REV: 20/06/11</p> <p>REV: 21/06/11</p> <p>REV: 22/06/11</p> <p>REV: 23/06/11</p> <p>REV: 24/06/11</p> <p>REV: 25/06/11</p> <p>REV: 26/06/11</p> <p>REV: 27/06/11</p> <p>REV: 28/06/11</p> <p>REV: 29/06/11</p> <p>REV: 30/06/11</p> <p>REV: 31/06/11</p> <p>REV: 32/06/11</p> <p>REV: 33/06/11</p> <p>REV: 34/06/11</p> <p>REV: 35/06/11</p> <p>REV: 36/06/11</p> <p>REV: 37/06/11</p> <p>REV: 38/06/11</p> <p>REV: 39/06/11</p> <p>REV: 40/06/11</p> <p>REV: 41/06/11</p> <p>REV: 42/06/11</p> <p>REV: 43/06/11</p> <p>REV: 44/06/11</p> <p>REV: 45/06/11</p> <p>REV: 46/06/11</p> <p>REV: 47/06/11</p> <p>REV: 48/06/11</p> <p>REV: 49/06/11</p> <p>REV: 50/06/11</p> <p>REV: 51/06/11</p> <p>REV: 52/06/11</p> <p>REV: 53/06/11</p> <p>REV: 54/06/11</p> <p>REV: 55/06/11</p> <p>REV: 56/06/11</p> <p>REV: 57/06/11</p> <p>REV: 58/06/11</p> <p>REV: 59/06/11</p> <p>REV: 60/06/11</p> <p>REV: 61/06/11</p> <p>REV: 62/06/11</p> <p>REV: 63/06/11</p> <p>REV: 64/06/11</p> <p>REV: 65/06/11</p> <p>REV: 66/06/11</p> <p>REV: 67/06/11</p> <p>REV: 68/06/11</p> <p>REV: 69/06/11</p> <p>REV: 70/06/11</p> <p>REV: 71/06/11</p> <p>REV: 72/06/11</p> <p>REV: 73/06/11</p> <p>REV: 74/06/11</p> <p>REV: 75/06/11</p> <p>REV: 76/06/11</p> <p>REV: 77/06/11</p> <p>REV: 78/06/11</p> <p>REV: 79/06/11</p> <p>REV: 80/06/11</p> <p>REV: 81/06/11</p> <p>REV: 82/06/11</p> <p>REV: 83/06/11</p> <p>REV: 84/06/11</p> <p>REV: 85/06/11</p> <p>REV: 86/06/11</p> <p>REV: 87/06/11</p> <p>REV: 88/06/11</p> <p>REV: 89/06/11</p> <p>REV: 90/06/11</p> <p>REV: 91/06/11</p> <p>REV: 92/06/11</p> <p>REV: 93/06/11</p> <p>REV: 94/06/11</p> <p>REV: 95/06/11</p> <p>REV: 96/06/11</p> <p>REV: 97/06/11</p> <p>REV: 98/06/11</p> <p>REV: 99/06/11</p> <p>REV: 100/06/11</p>	<p>REV: 01/06/11</p> <p>REV: 02/06/11</p> <p>REV: 03/06/11</p> <p>REV: 04/06/11</p> <p>REV: 05/06/11</p> <p>REV: 06/06/11</p> <p>REV: 07/06/11</p> <p>REV: 08/06/11</p> <p>REV: 09/06/11</p> <p>REV: 10/06/11</p> <p>REV: 11/06/11</p> <p>REV: 12/06/11</p> <p>REV: 13/06/11</p> <p>REV: 14/06/11</p> <p>REV: 15/06/11</p> <p>REV: 16/06/11</p> <p>REV: 17/06/11</p> <p>REV: 18/06/11</p> <p>REV: 19/06/11</p> <p>REV: 20/06/11</p> <p>REV: 21/06/11</p> <p>REV: 22/06/11</p> <p>REV: 23/06/11</p> <p>REV: 24/06/11</p> <p>REV: 25/06/11</p> <p>REV: 26/06/11</p> <p>REV: 27/06/11</p> <p>REV: 28/06/11</p> <p>REV: 29/06/11</p> <p>REV: 30/06/11</p> <p>REV: 31/06/11</p> <p>REV: 32/06/11</p> <p>REV: 33/06/11</p> <p>REV: 34/06/11</p> <p>REV: 35/06/11</p> <p>REV: 36/06/11</p> <p>REV: 37/06/11</p> <p>REV: 38/06/11</p> <p>REV: 39/06/11</p> <p>REV: 40/06/11</p> <p>REV: 41/06/11</p> <p>REV: 42/06/11</p> <p>REV: 43/06/11</p> <p>REV: 44/06/11</p> <p>REV: 45/06/11</p> <p>REV: 46/06/11</p> <p>REV: 47/06/11</p> <p>REV: 48/06/11</p> <p>REV: 49/06/11</p> <p>REV: 50/06/11</p> <p>REV: 51/06/11</p> <p>REV: 52/06/11</p> <p>REV: 53/06/11</p> <p>REV: 54/06/11</p> <p>REV: 55/06/11</p> <p>REV: 56/06/11</p> <p>REV: 57/06/11</p> <p>REV: 58/06/11</p> <p>REV: 59/06/11</p> <p>REV: 60/06/11</p> <p>REV: 61/06/11</p> <p>REV: 62/06/11</p> <p>REV: 63/06/11</p> <p>REV: 64/06/11</p> <p>REV: 65/06/11</p> <p>REV: 66/06/11</p> <p>REV: 67/06/11</p> <p>REV: 68/06/11</p> <p>REV: 69/06/11</p> <p>REV: 70/06/11</p> <p>REV: 71/06/11</p> <p>REV: 72/06/11</p> <p>REV: 73/06/11</p> <p>REV: 74/06/11</p> <p>REV: 75/06/11</p> <p>REV: 76/06/11</p> <p>REV: 77/06/11</p> <p>REV: 78/06/11</p> <p>REV: 79/06/11</p> <p>REV: 80/06/11</p> <p>REV: 81/06/11</p> <p>REV: 82/06/11</p> <p>REV: 83/06/11</p> <p>REV: 84/06/11</p> <p>REV: 85/06/11</p> <p>REV: 86/06/11</p> <p>REV: 87/06/11</p> <p>REV: 88/06/11</p> <p>REV: 89/06/11</p> <p>REV: 90/06/11</p> <p>REV: 91/06/11</p> <p>REV: 92/06/11</p> <p>REV: 93/06/11</p> <p>REV: 94/06/11</p> <p>REV: 95/06/11</p> <p>REV: 96/06/11</p> <p>REV: 97/06/11</p> <p>REV: 98/06/11</p> <p>REV: 99/06/11</p> <p>REV: 100/06/11</p>
--	--	---	--	--	--


Powaboom Diagram - SE568a01



Copyright and rights are the property of Johnston Sweepers Ltd.


Variabrush / Rotatilt Diagram Type B Switches - SE571z03

Copyright and rights are the property of Johnston Sweepers Ltd.



Doc No	EP222842	Rev	SW	10/11/06	
Model	VT VS RANGE	Doc No	SE571z03	Rev	00
VARIABRUSH/ROTATILT					
<small>THE COMPANY ACCEPTS NO LIABILITY FOR LOSS OF PROFITS OR DAMAGE TO PROPERTY OR PERSONS ARISING FROM THE USE OF THIS DOCUMENT WITHOUT THE EXPRESS WRITTEN CONSENT FROM JOHNSTON SWEEPERS LIMITED.</small>					
<small>JOHNSTON SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK. RH4 1XF</small>					

Independent / Simultaneous Sweep Diagram Type B Switches - SE572z03



Johnston SWEEPERS LIMITED
CURTIS ROAD, DORKING, SURREY, UK, RH4 1XF

INDEPENDANT / SIMULTANEOUS SWEEP


SE572z03 00

REVISION 00

Copyright and rights are the property of Johnston Sweepers Ltd.

Water Recirculation Diagram Type B Switches - SE573z03

Copyright and rights are the property of Johnston Sweepers Ltd.



Johnston
SWEEPERS LIMITED
CURTIS ROAD, DORKING, SURREY, UK. RH4 1XF

THE COMPANY'S COPYRIGHT
IN THIS DOCUMENT IS
RESERVED AND NO PART
HEREOF MAY BE REPRODUCED
OR TRANSMITTED IN ANY
FORM OR BY ANY MEANS
WITHOUT THE WRITTEN
PERMISSION OF JOHNSTON
SWEEPERS LIMITED.

RECIRC WATER

SE573z03


REV: 00

DATE: 08/11/06

PROJECT: VT VS RANGE

DOC. NO: SE573z03

Varagap Option Diagram Type B Switches - SE574z03



Johnston SWEEPERS LIMITED
 GRAYS ROAD, DORRIS, SURREY, UK. RM4 1JF


IT IS AN INSTRUMENT OF TRUST AND CONFIDENCE AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, WITHOUT THE EXPRESS WRITTEN PERMISSION OF JOHNSTON SWEEPERS LIMITED.

TITLE: VARAGAP OPTION
 PROJECT: VT VS RANGE
 DRAWING NO: SE574z03
 REVISION: 00


Copyright and rights are the property of Johnston Sweepers Ltd.

Supawash Option Diagram Type B Switches - SE575z03

Copyright and rights are the property of Johnston Sweepers Ltd.




Additional Throttle Diagram - SE578a01



Copyright and rights are the property of Johnston Sweepers Ltd.


Additional WSB Water Option Diagram Type B Switches - SE579z03

Copyright and rights are the property of Johnston Sweepers Ltd.



REV. NO.	REV. DATE	REV. DESCRIPTION
00	08/11/08	VT VS RANGE
01	08/11/08	SE579z03
ADDITIONAL WSB WATER		
 JOHNSTON SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK, RH4 1XF		

Program / Maxigap / Varagap Diagram Type B Switches - SE580z03



IT IS AN INSTRUMENT OF THE COMPANY'S COPYRIGHT. THIS COPY OR REPRODUCTION IS NOT VALID WITHOUT WRITTEN PERMISSION FROM JOHNSTON SWEEPERS LIMITED. CURTIS ROAD, DORKING, SURREY, UK. RH4 1SF


Johnston SWEEPERS LIMITED

AUXILIARY PROGRAM BUTTON
MAXIGAP AND VARAGAP
SCHEMATIC

REV: 00728242
PART: SW
V. RANGE
REV. NO. SE580z03
REV. NO. 00

Copyright and rights are the property of Johnston Sweepers Ltd.


VS Powapak D-Tec Diagram Type B Switches - SE585z04b



<p>JOHNSTON SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK. RH4 1XF</p>	<p>IT IS AN IMPROVEMENT OF THIS DRAWING AND DESIGN IN THE DRAWING AND DESIGN IT'S CONTENTS TO ANY THIRD PARTY WITHOUT THE WRITTEN CONSENT FROM JOHNSTON SWEEPERS LIMITED.</p>	<p>TITLE VS POWAPAK CONTROLS D-TEC CONTROL BOX SCHEMATIC</p>	<p>DRAWN BY R57/04/09</p>
	<p>DATE 20.05.87</p>	<p>VS RANGE</p>	<p>REV. NO. SE585z04b</p>


Copyright and rights are the property of Johnston Sweepers Ltd.

VS Powapak Controls Diagram Type B Switches - SE585z04c



REV. NO.	REV. RANGE	REV. DATE
703587	VS RANGE	28/04/09
TITLE: VS POWAPAK CONTROLS POWAPAK SCHEMATIC		
THE COMPANY'S COPYRIGHT AND ALL RIGHTS ARE RESERVED AND WILL REMAIN THE PROPERTY OF JOHNSTON SWEEPERS LIMITED. IT IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, WITHOUT THE WRITTEN PERMISSION OF JOHNSTON SWEEPERS LIMITED.		
CURTIS ROAD, DORKING, SURREY, UK, RH4 1XF		
LOOM NO.	REV. NO.	REV. DATE
SE585z04c	A	

Iveco Stage 3a HP Engine Diagram - SE587z03aA



Johnston
SWEEPERS LIMITED
CURTIS ROAD, DORNING, SURREY, UK, RH4 1XF


SE587z03b

IVECO S3A
AUXILIARY ENGINE
SWITCH BOX

REV.	DATE
001	03/04/201
002	03/04/201
003	03/04/201
004	03/04/201
005	03/04/201
006	03/04/201
007	03/04/201
008	03/04/201
009	03/04/201
010	03/04/201
011	03/04/201
012	03/04/201
013	03/04/201
014	03/04/201
015	03/04/201
016	03/04/201
017	03/04/201
018	03/04/201
019	03/04/201
020	03/04/201
021	03/04/201
022	03/04/201
023	03/04/201
024	03/04/201
025	03/04/201
026	03/04/201
027	03/04/201
028	03/04/201
029	03/04/201
030	03/04/201
031	03/04/201
032	03/04/201
033	03/04/201
034	03/04/201
035	03/04/201
036	03/04/201
037	03/04/201
038	03/04/201
039	03/04/201
040	03/04/201
041	03/04/201
042	03/04/201
043	03/04/201
044	03/04/201
045	03/04/201
046	03/04/201
047	03/04/201
048	03/04/201
049	03/04/201
050	03/04/201
051	03/04/201
052	03/04/201
053	03/04/201
054	03/04/201
055	03/04/201
056	03/04/201
057	03/04/201
058	03/04/201
059	03/04/201
060	03/04/201
061	03/04/201
062	03/04/201
063	03/04/201
064	03/04/201
065	03/04/201
066	03/04/201
067	03/04/201
068	03/04/201
069	03/04/201
070	03/04/201
071	03/04/201
072	03/04/201
073	03/04/201
074	03/04/201
075	03/04/201
076	03/04/201
077	03/04/201
078	03/04/201
079	03/04/201
080	03/04/201
081	03/04/201
082	03/04/201
083	03/04/201
084	03/04/201
085	03/04/201
086	03/04/201
087	03/04/201
088	03/04/201
089	03/04/201
090	03/04/201
091	03/04/201
092	03/04/201
093	03/04/201
094	03/04/201
095	03/04/201
096	03/04/201
097	03/04/201
098	03/04/201
099	03/04/201
100	03/04/201


Copyright and rights are the property of Johnston Sweepers Ltd.

Iveco Stage 3a HP Engine Diagram - SE587z03bA



IVECO S3A
 AUXILIARY ENGINE
 ENGINE LOOM
 SE587z03b A
 JOHNSTON SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK, RH4 1YF
 IT IS AN INSTRUMENT OF THE COMPANY'S PROPERTY TO BE KEPT IN GOOD ORDER AND RETURNED TO THE COMPANY WITHOUT DELAY.


Iveco Stage 3a HP Engine Diagram - SE587z03cA



Copyright and rights are the property of Johnston Sweepers Ltd.


John Deere Tier 3 HP Engine Diagram - SE588z03a

Copyright and rights are the property of Johnston Sweepers Ltd.



GENERAL TOLERANCES	VIEWING QUANTITY	DATE	REVISION BY	DATE
PRODUCT	PROJECT	16.06.2009	DAVIS	16.06.2009
RESPONSIBLE DEPARTMENT	DRAWING NUMBER	TITLE (S/PROJECT/TITLE)		
C-D	SE588Z03A	John Deere 125 HP Tier 3 Aux Engine Cont		
SCALE	SHEET	FIGURE NUMBER	REVISION	EA
NTS 1/3	1/3	SE588Z03A	A	703889

John Deere Tier 3 HP Engine Diagram - SE588z03b




GENERAL REQUIREMENTS	REVISIONS	REVISION	DATE	REVISION BY	DATE
			16.06.2009	DAVIS	16.06.2009
PROJECT	PROJECT	THE OPERATOR TITLE	John Deere 125 HP Tier 3 Aux. Engine Cont.		
RESPONSIBLE DEPARTMENT	DOCT. TYPE	VERSION	SHEET	DOCUMENT NUMBER	EN
C-D	ACD	01	2 / 3	SE588Z03B	A
			NTS		703889

SE588Z03C


Copyright and rights are the property of Johnston Sweepers Ltd.

John Deere Tier 3 HP Engine Diagram - SE588z03c



REVISED	03	SE588z03c	VT	13/10/08
REVISION	03	SE588z03c	VT	13/10/08
JOHN DEERE 125 HP TIER 3 AUX ENGINE CONTROLS MANAGE/BOX SCHEMATIC				
JOHNSTON SWEEPERS LIMITED GURTES ROAD, DOBKING, SURREY, UK, RH14 5JF				

Iveco Stage 3a SP Engine Diagram - SE589z03aA




SE589z03b

<p>SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK. RH4 1XF</p>		<p>IT IS AN INSTRUMENT OF THE COMPANY'S COPYRIGHT. TO COPY OR COMMUNICATE IN ANY MANNER WITHOUT WRITTEN PERMISSION FROM JOHNSTON SWEEPERS LIMITED.</p>	
<p>TITLE: IVECO STAGE 3 STANDARD POWER AUXILIARY ENGINE</p>			
<p>REV: 733576</p>	<p>REV: 733576</p>	<p>REV: 733576</p>	<p>REV: 733576</p>
<p>PAGE NO: VT</p>	<p>PAGE NO: VT</p>	<p>PAGE NO: VT</p>	<p>PAGE NO: VT</p>
<p>REV: SE589z03a</p>		<p>REV: SE589z03a</p>	
<p>PAGE NO: A</p>		<p>PAGE NO: A</p>	


Copyright and rights are the property of Johnston Sweepers Ltd.

Iveco Stage 3a SP Engine Diagram - SE589z03bA




REV: 703576	REV: 50	REV: 13	REV: 14	REV: 15	REV: 16	REV: 17	REV: 18	REV: 19	REV: 20
PROJECT: VT	RANGE: SE589z03b	TITLE: IVECO STAGE 3 STANDARD POWER AUXILIARY ENGINE							
IT IS AN INSTRUMENT OF THE COMPANY'S COPYRIGHT AND IS NOT TO BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS WITHOUT THE WRITTEN PERMISSION OF JOHNSTON SWEEPERS LIMITED.									
JOHNSTON SWEEPERS LIMITED CURTIS ROAD, DORKING, SURREY, UK, RH4 1YF									

John Deere Tier 3 SP Engine Diagram - SE590z03



Copyright and rights are the property of Johnston Sweepers Ltd.

Low Pressure Water Pump Bypass - Option - Diagram SE687z03



IT IS AN IMPROVEMENT OF THE ORIGINAL DESIGN AND IS NOT TO BE USED IN THE ORIGINAL DESIGN UNLESS SPECIFICALLY APPROVED BY JOHNSTON SWEEPERS LIMITED.	FILE	WATER PUMP BYPASS (OPTION)	REV	00
SE558z03	SE575z03	SE687z03	SE687z03	00



CHAPTER 10

Water System

Table of Contents

Section	Page
Introduction	
General Description	10 : 2
Circuit Pressures	10 : 2
Component Maintenance and Settings	
Water Pump	10 : 3
Relief Valve	10 : 4
Solenoid Valves	10 : 4
Hydrant Filler	10 : 4
Recirculation Valves	10 : 5
Piping Diagram	10 : 6
Supawash Pump	
Pump Repair	10 : 8
Seal and Valve Maintenance	10 : 9
Exploded View of Pump	10 : 12
Circuit Diagrams	
Low Pressure - Single Sweep	10 : 13
Low Pressure - Dual Sweep	10 : 14
Microtrap - Single Sweep	10 : 15
Microtrap - Dual Sweep	10 : 16
Supawash	10 : 17

GENERAL DESCRIPTION

Pressure for the water supply is provided by a twin diaphragm pump hydraulically driven from the auxiliary engine. Pressure regulation is by a relief valve situated at the rear of the machine. Filtration is by two filters, one mounted within the water tank and a second in-line type located at the right hand rear of the machine. An isolator valve is built into the in-line filter for ease of element servicing. All sweeping spray jets are controlled by simple solenoid valves, manifold mounted within the systems locker.

Control of the washdown hose and wanderhose water injection is by manual valves at the rear of the machine subframe.

SUPAWASH OPTION

This optional equipment comprises a hydraulically driven high pressure water pump, and a hand lance mounted on the chassis of the machine with a 15 metre hose wound onto a recoiling reel.

Front and nozzle spraybars are optional equipment.

Supawash Unloader Valve - Pressure Setting

1. Ensure that the hydraulic relief valve has been set as outlined in section 8.
2. Fit a hydraulic test gauge to the Supawash manifold (T13).
3. Disconnect the 3/8" bypass pipe at the unloader valve and plug the hose end.
4. Turn on the front spraybar tap.
5. Activate the Supawash and increase the engine speed to 2000 rpm. Check to see if any water is leaking from the bypass port on the unloader, if not loosen the retaining nut on the top of the unloader and unscrew anticlockwise until water dribbles from the bypass port. Gently turn the adjuster clockwise until water stops dribbling, then turn the adjuster 1/2 turn clockwise and lock off the retaining nut. The operational pressure at the manifold should be 100 bar nominal. If the pressure is higher check again for blocked jets. If the pump operates at a pressure in excess of 100 bar there is a problem that will effect the life of the pump and invalidate any warranty.

NB - Do not turn off the front Supawash spraybar or water will be ejected from the bypass valve where the hose has been removed.

6. Stop the engine and reconnect the bypass hose.


CIRCUIT PRESSURES

Two test points are provided for checking the water pressures.

Test Point No.	Function
WTP	Dust Suppression Sweep System
T13	Supawash System

WATER PUMP

- A) Manifold
- B) Suction Port
- C) Delivery Port
- D) Suction Valve
- E) Delivery Valve
- F) Valve Sealing Rings
- G) Pump Chamber
- H) Tension Pad Bolts
- J) Tension Pads
- K) Diaphragms
- L) Connecting Rods



M. 0017

The assembly of the twin diaphragm pump is quite simple and straightforward, but attention to the undermentioned points will afford economy by prolonging the life of the pump and, more especially, the expendable components.

- 1 Diaphragms -
When replacing a diaphragm, turn the crankshaft until the relative connecting rod is at TDC so that when securing the diaphragm and the tension pad by means of the tension pad bolt, the periphery of the diaphragm is free of the crank case.
Ensure that the tension pad is pulled down onto the connecting rod.
- 2 Pump Chambers -
Before fitting a pump chamber, turn the crankshaft until the relative diaphragm is at the centre of its stroke, i.e. so that the periphery of the diaphragm is just resting on the face of the crankcase. Place the pump chamber in position, place the bolts and nuts in position and tighten 'finger tight'. Tighten down, but make sure that the pump chamber is pulled down square so that the lower face of the chamber is correctly located against the crankcase.
- 3 Manifolds and Valves -
Fit the valve sealing rings onto the valve seat. Place the delivery valve (stem upwards) over the delivery orifice of the pump chamber and push the sealing ring down so that it is flush with the pump chamber. Fit the suction valves in a similar manner, but with stem downwards. Place the manifold over the valves and see that it sits square. If the manifold does not sit square, then either the valves or the sealing rings are not correctly located. Place the securing bolts in position and pull down squarely.


It is important that these instructions are carried out, especially with regard to the fitting of the manifolds, to ensure a satisfactory seal at the valve sealing rings. Unless these instructions are followed, leakage will be experienced at the joint between the manifold and the pump chambers. On dismantling a pump for examination, if the valve sealing rings have taken on a permanent set to their location (roughly triangular in cross section), they should be replaced.

RELIEF VALVE

This valve is factory set and should not normally be touched, but should it be necessary to make adjustments, the pressure is set as follows.

PRESSURE SETTING

Remove the cover (A) and loosen adjuster locknut (B). Connect a pressure gauge to the test point located in the systems locker. With the auxiliary engine running at low idle speed (750/800), and all water sprays switched off, turn adjuster screw (C) until gauge reads 3.5 bar (50 psi). Tighten locknut and replace cover.




SOLENOID VALVES

Solenoid valves control the water spray jets and are located in the systems locker. Each valve incorporates a filter (A) in its suction port and a manual lift override lever (B). Turning the lever anticlockwise opens the valve; clockwise closes it. This manual lift facility can be used when draining the water system in winter (see Operator's Guide, Chapter 3) and for actuating the valve should it for any reason fail to operate electrically.


The valve is readily dismantled for inspection or cleaning by unscrewing the retaining cap (C) through the coil (D).

To access the armature, unscrew the four retaining screws (E) and remove the armature cover (F). The armature (G) can be removed. When refitting parts ensure the 'O' ring (H) is in good condition and located correctly.




HYDRANT FILTER

Periodically the hydrant filler filter (A) should be cleaned, or replaced if damaged. To gain access to the filter, unscrew the hydrant coupling (B) and withdraw the filter from its housing (C).



RECIRCULATION VALVES




95MA.031

There is no routine maintenance required on these valves.



Isolate the air supply at the Filter regulator unit before removing the valve for maintenance, cleaning or replacement

Piping Diagram



Copyright and rights are the property of Johnston Sweepers Ltd.

Illustration Component Key

- 1 Water tank
- 2 Tank overflow vent
- 3 Water pump - output 28 l/m
- 4 Water tank primary filter
- 5 Suction filter
- 6 Tank flushing ports
- 7 Tank filler port - hosepipe
- 8 Water level sight glass
- 9 Tank drain/flushing valve
- 10a Hydrant filler port for water tank
- 10b Recirc water body filler *
- 11 'Type A' anti syphon water break
- 12 Relief valve
- 13 Washdown hose
- 14 Wanderhose and Littasnatch valves *
- 15 Water valve manifold - see table below
 - (A) Supply
 - (B) Manual override levers
 - WTP Water test point

* Options

VS & VT MODULAR SERIES - WATER SYSTEM - WATER VALVE STATION UTILISATION

VALVE	M/C TYPE		1	2
	VT	VS	SINGLE	DUAL
WO1	v	v	Wide sweep brush	Wide sweep brush
WO2	v	v	Gutter	LH gutter
WO3	v	v	Channel brush	LH channel brush
WO4	v	v	Nozzle	LH nozzle
WO7	v	v	<i>Not fitted</i>	RH gutter
WO8	v	v	<i>Not fitted</i>	RH channel brush
WO9	v	v	<i>Not fitted</i>	RH nozzle
W10	v	v	<i>Not used on basic m/c</i>	<i>Not used on basic m/c</i>

Note:

(1) Where the words 'not used' appear this means that the valve is fitted to the mounting station and is only used for various option.

(2) Where the words 'not fitted' appear this means that the valve is not fitted to the mounting station.


Copyright and rights are the property of Johnston Sweepers Ltd.

Water Pump Repair

Water pumps by their very nature are subject to erosion and wear from the process of pumping water. The life of the pump will depend on the quality of the water being used. The more particles that are in suspension in the water the sooner the seals and valves in the pump will wear and require replacing and are therefore considered as consumable items.

The main components in the pump that will require servicing are the suction and discharge valves and the seals on the plunger pipes.

A pump working correctly will normally not have any water leaks. If the plunger seals wear water will leak from the underside of the pump as shown below.



A drip ever 5 -10 seconds is an indication that the seals need replacing in the very near future. A continuous drip from underneath the pump shows the seals are severely worn and require urgent and prompt replacement. Shown by the arrows in the above picture.










If a steady stream of water leaking from the pump is observed the pump should NOT be used. Should the pump be used in this condition water will be drawn back into the crankcase by the motion of the plungers. This water ingress into the crankcase will cause a catastrophic failure of the pump.










When the suction and discharge valves wear the out put of the pump will be reduced and this will be noticed as reduced output from the spray jets.

**P22/34-100 Johnston Waterpump 283701-1
Seal and Valve Maintenance Instructions**







The following shows the overhaul procedure for the valves and plunger seals


Copyright and rights are the property of Johnston Sweepers Ltd.

		
<p>1. With a 22mm socket, remove the three discharge valve plugs (43) from the top of the manifold.</p>	<p>2. With a pair of needle nose pliers remove the spring tension cap (34), spring (35) and plate (36)</p>	
		
<p>3. Use a valve extractor tool (99.061) to remove the valve seats (37)</p>	<p>4. Inspect the valve seat (37) and valve seat (36) for signs of wear or cavitation and replace as necessary.</p>	<p>5. Using an 8mm Allen key remove the inner hexagon screws (45)</p>
		
<p>6. With a rubber mallet tap the back of the valve casing (29) and pull the valve casing (29) off the plungers (24a).</p>	<p>7. Using a 6mm Allen key remove the two inner hexagon screws (46).</p>	<p>8. Separate the intermediate casing (48) from the valve casing (29)</p>

		
<p>9. Remove and inspect the low pressure seal (50) and replace if necessary.</p>	<p>10. Turn over intermediate casting (48) Remove and inspect the high pressure seal (31) and the support ring (32) replace if necessary.</p>	<p>11. Remove the seal case (39) from the valve casing (29) and inspect both O Rings (40) for wear.</p>
		
<p>12. Using needle nose pliers, remove the spring tensioning caps (34), valve spring (35), valve plate (36) from the valve casing (29) Using a valve extractor (99.061) to remove the valve seat (37) from the valve casing (29).</p>	<p>13. Inspect the valve seat (37) and valve seat (36) for signs of wear or cavitation and replace as necessary.</p>	<p>14. Install the inlet valve assembly (34 – 38) back into the valve casing. Ensure the “fingers” of the spring tensioning cap (34) DO NOT obstruct the cross bore in the valve casing (29).</p>
		
<p>15. Install the seal case (39) with O Rings (40) into the valve casing (29)</p>	<p>16. Install the support ring (32) and the high pressure seal (31) into the intermediate plate (48)</p>	<p>17. Lubricate the low pressure seal (50) and install into the intermediate casing (48).</p>

Copyright and rights are the property of Johnston Sweepers Ltd.


		
<p>18. Replace the three spacer sleeves (26a) over the plunger (24a) with the flanged side toward the valve casing (29)</p>	<p>19. Install the pressure rings (30) over the plungers (24a). Make sure that the small o ring (49) is in place in the intermediate casing (49)</p>	<p>20. Secure the intermediate casing (48) to the valve casing (29) with the inner hexagon screws (46). Torque to 12 NM.</p>
		
<p>21. Place the valve casing (29) over the plungers (24a). Secure with inner hexagon screws (45) Torque evenly to 45 NM</p>	<p>22. Install the high pressure valve assemblies with o rings (34 – 38) Ensuring the fingers of the spring tensioning cap (34) DO NOT obstruct the cross bore in the head (29).</p>	<p>23. Replace the high pressure plugs (43) and torque to 70 NM.</p>

Exploded view of Pump



Item Number	Quantity	Part Number	Description
19	1	283701-13	Woodruff Key
20	3	283701-14	Connecting Rod
24A	3	283701-12	Ceramic Liner
31,32,40,49,50	1 Kit	283701-10	Plunger Seal kit - for 3 plungers
34,35,36,37,38	1 Kit	283701-11	Valve Kit - for the 6 valves

Copyright and rights are the property of Johnston Sweepers Ltd.

Water System Low Pressure Single Sweep - Diagram SW511a02




Water System Low Pressure Dual Sweep - Diagram SW511b02




Copyright and rights are the property of Johnston Sweepers Ltd.

Water System Microtrap Single Sweep - Diagram SW512a02




Water System Microtrap Dual Sweep - Diagram SW512b02



Copyright and rights are the property of Johnston Sweepers Ltd.

Water System Supawash - Diagram SW513a02

Copyright and rights are the property of Johnston Sweepers Ltd.



DATE	01.04.2011
RELEASED BY	COTTON
DATE	25.03.2011
ORDERED BY	FERGUSON
TITLE SUPPLEMENT/TITLE	High Pressure Water
REVISION	01
SCALE	1:1
SHEET	1/1
DOCUMENT NUMBER	SW513A02
REVISION	B
EVA	7067/02

GENERAL USE/ITEMS	ISO 2768 mK
VELOCITIES/TOLERANCES	ISO 1920-D
VELOCITY/QUALITY	ISO 5817 D
PRODUCT	LR Range
PROJECT	Site Ancillaries
RESPONSIBLE ENGINEER	C-D
DOC TYPE	ACC
REVISION	01

RETURNED TO	4
RETURNED TO	5
RETURNED TO	6
RETURNED TO	7
RETURNED TO	A3

CHAPTER

11

Pneumatic System

Table of Contents

Section	Page
Introduction	
General Description	11 : 2
Circuit Pressures	11 : 2
Pneumatic Pipe Colours	11 : 2
Valve Identification/Location	11 : 3
Component Removal	
Air Filtration and Regulator (FR)	11 : 4
Pneumatic Valve Island	11 : 4
Wide Sweep Brush Regulator Maintenance	11 : 6
Circuit Diagrams	
Maxigap Single Sweep	11 : 7
Maxigap Dual Sweep	11 : 8
Recirculation Water Option	11 : 9
Recirculation Water Option	11 : 9
Autolok Cylinder Option	11 : 10
Mesh Shakers and Littasnatch Options	11 : 11
Hydrodrive Gearbox	11 : 12
Varagap Option	11 : 13

GENERAL DESCRIPTION

The air supply for the pneumatic system is taken from the vehicle braking system via a safety regulating valve that ensures the braking system receives priority in the event of a failure to the sweeper air system. A filter regulator unit with integral shut off/drain facility and low air pressure warning buzzers are located within the systems locker, as are the electrical solenoid control valves for operation of channel brush/ nozzle and wide sweep brush, and intake duct flap. Wide sweep brush balance adjustment is provided by pressure regulators.



Safety Precautions



Before servicing any components on this system, the air supply should be shut off by means of the shut off valve mounted on top of the filter regulator unit. This not only severs the pneumatic supply, it also exhausts the air from the system causing the nozzle and wide sweep brush to lower. Wait approximately 15 seconds to allow air to completely exhaust before carrying out any work. The shut off valve does not drain air from the vehicle braking system.

CIRCUIT PRESSURES

A test point PTP (on piping diagram) is provided in the systems locker to carry out pressure checks, i.e. 8.0 bar (115 PSI).

The pressure in the Powathrust system is preset at 3.5 bar.

The pressure in the Powascrub system (option) is preset at 2 bar.

- 1 First ensure truck air system is up to pressure and sweepgear is lifted.
- 2 Fit a 25 bar minimum pressure gauge to test point PTP.

If pressure is incorrect, adjustment is carried out by turning the regulator control on the filter regulator unit.

NB : Provided in the systems locker is an air charge point (AC) via an airline push in connector supplied with the sweeper.


PNEUMATIC PIPE COLOURS

A system of colour coding has been introduced to assist pipe identification and fault finding. The following colours have been adopted.

- R** = Red - used for live feed/supply
- U** = Blue - used for switched supply via valve or tap
- B** = Black - used for permanent vent/exhaust line

VALVE IDENTIFICATION/LOCATION

SYSTEMS LOCKER



95MA. 001-7

Copyright and rights are the property of Johnston Sweepers Ltd.


AIR FILTRATION AND REGULATOR (FR)

A filter regulator unit, located in the systems locker on the left hand side of the body, filters the air for the sweeper section of the pneumatic system to prolong the life of the components served by it.

Before carrying out any major work on the unit, other than that described in the Routine Maintenance Section of the Operator's Guide, it will be necessary to remove it from the locker by first draining the vehicle air system, then disconnecting the supply pipes and releasing the fixing bolts.

PNEUMATIC VALVE ISLAND

The pneumatic valve island is a modular unit comprising various valve segments. Each valve segment has an indicator light that illuminates when energised (A) and a manual override button (B) for ports 2 or 4 on each segment



The segments are identified by a code and are not all the same - see following tables.

To replace a valve segment -

- 1) Remove the 4 fixing screws (C).
- 2) Remove the 4 socket head screws (D).
- 3) Remove the valve cover containing the valve operating coils (E).
- 4) Unscrew (F) each side of the segment to be replaced.
- 5) Fold open the segment (G) and replace ensuring the rubber gasket (H) is in position.
- 6) Tighten screws (F).
- 7) Replace top cover (E).
- 8) Replace screws (D).

Pneumatic Valve Island modus operandi

Single Configuration

Valve	Segment Code	Function	
		Port 4 / LED 14	Port 2 / LED 12
V1 & V2	NC6U or TC6U	V1 = Maxigap (NC)	V2 = Nozzle lower (NO)
V3 & V4	NC6U or TC6U	V3 = CB lok & Autolok* (NC)	V4 = WSB lower (NO)
V5 & V6	NB6U or TB6U	V5 = CB lower (NO)	Port plugged
V7 & V8	NA6U or TA6U	V7 = Powathrust (NC)	V8 = Powascrub (NC)
V9 & V10	Blank		
V11	NG6U or TG6U	Flap – Full Bore (NC)	Flap – Annulus (NO)
V12	Blank		
V13	Blank		
V14* & V15*	NA6U or TA6U	Water recirculation (NC)	Port plugged
V16* & V17*	NB6U or TN6U	Varagap = Full Bore (NO)	Varagap = Annulus (NO)

* Option

Dual Configuration

Valve	Segment Code	Function	
		Port 4 / LED 14	Port 2 / LED 12
V1 & V2	NC6U or TC6U	V1 = Maxigap LH (NC)	V2 = Nozzle lower LH (NO)
V3 & V4	NC6U or TC6U	V3 = CB lok & Autolok (NC)	V4 = WSB lower (NO)
V5 & V6	NB6U or TB6U	V5 = CB lower LH (NO)	V6 = CB lower - RH (NO)
V7 & V8	NA6U or TA6U	V7 = Powathrust (NC)	V8 = Powascrub (NC)
V9 & V10	NC6U or TC6U	V9 = Maxigap RH (NC)	V10 = Nozzle lower - RH (NO)
V11	NG6U or TG6U	Flap LH – Full Bore (NC)	Flap LH – Annulus (NO)
V12	NG6U or TG6U	Flap RH – Full Bore (NC)	Flap RH – Annulus (NO)
V13	NG6U or TG6U	WSB balance LH (NC)	WSB balance RH (NO)
V14* & V15*	TA6U or Blank	Water recirculation LH (NC)	Water recirculation RH (NC)
V16* & V17*	TB6U or Blank	Varagap = Full Bore (NO)	Varagap = Annulus (NO)

* Option

Revision 00 dated 10/11/05

Note: 12 volt segments start with T***
24 volt segments start with N***

Copyright and rights are the property of Johnston Sweepers Ltd.

WIDE SWEEP BRUSH REGULATOR MAINTENANCE

Before any work can be carried out on these units, they must be removed from their locations under the ends of the subframe crossmember+ as follows.

Exhaust the system using filter regulator shut off valve, disconnect pipes from regulator and shuttle valve, unscrew regulator securing nut. The regulator, shuttle and non-return valves can be removed as a complete assembly.

REGULATOR

Remove the regulator by undoing the securing nut (A). Use retaining ring pliers to remove the top plate (6) and retaining ring (7). Pull cap (8) and 'O' ring (9) from body.

Unscrew socket head screw (1), then remove button (2), spring (3), knob (4), tumblers (5), couple (10) and 'O' ring (11).

Remove, as an assembled unit, the adjusting screw (12) with upper and lower piston assemblies (Items 13 through 20). Remove spring (21).


Unscrew the adjusting screw (12), then separate upper and lower piston assemblies (Item 13 through 20). The adjusting screw has left hand threads. Make sure 'O' ring (19) remains attached to the lower piston. If not, retrieve it from inside the upper piston (13).

Unscrew bottom plug (22) to gain access to the parts (23 through 36) located in the lower portion of the body.

Clean and inspect each item for damage.


A repair kit, Part No. 253-10, is available comprising Items 9, 11, 12, 14, 19, 20, 23-27, 29, 30 and 36.

When reassembling, lightly smear the 'O' rings and rubbers with a silicon grease. Reassemble in the reverse procedure.




PC. 0014

Copyright and rights are the property of Johnston Sweepers Ltd.



Make sure retaining ring (7) is fully seated in the groove in the body before testing or refitting onto the machine.

Maxigap Single Sweep - Diagram SP541a02



Johnston SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK, RH4 1JF


THE COMPANY'S CONTRACTOR TO THE MODERN ROADWORKERS' ASSOCIATION (MRA) FOR THE SUPPLY AND INSTALLATION OF SWEEPERS AND RELATED EQUIPMENT.

Johnston SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK, RH4 1JF

SP541a02
 PNEUMATIC CIRCUIT
 MAIN SYSTEM
 SINGLE SWEEP

REV: 01
 DATE: 09/09/09
 DRAWN BY: VT/VAS
 CHECKED BY: SP541a02

Maxigap Dual Sweep - Diagram SP542a02



Johnston SWEEPERS LIMITED
 CURTIS ROAD, DORKING, SURREY, UK. RH4 1XF

THE ONLY REPRESENTATIVE OF THE COMPANY'S COPYRIGHT TO COPY OR TRANSMIT IN ANY MANNER WITHOUT WRITTEN PERMISSION FROM JOHNSTON SWEEPERS LIMITED.


TITLE: PNEUMATIC CIRCUIT
MAIN SYSTEM: DUAL SWEEP

REV. NO.: SP542g02
REV. DATE: 19/07/2008
REV. BY: VT/VIS

FIGURE NO.: 09


Copyright and rights are the property of Johnston Sweepers Ltd.

Recirculation Water Option - Diagram SP543a02



REV	REV	REV	REV
01	02	03	04
DATE	DATE	DATE	DATE
01/01/05	01/01/05	01/01/05	01/01/05
BY	BY	BY	BY
VT/AS	VT/AS	VT/AS	VT/AS
PROJECT	PROJECT	PROJECT	PROJECT
SP543a02	SP543a02	SP543a02	SP543a02
DESCRIPTION	DESCRIPTION	DESCRIPTION	DESCRIPTION
PNEUMATIC CIRCUIT	PNEUMATIC CIRCUIT	PNEUMATIC CIRCUIT	PNEUMATIC CIRCUIT
RECIRC WATER	RECIRC WATER	RECIRC WATER	RECIRC WATER
COMPONENT BOUNDARY	COMPONENT BOUNDARY	COMPONENT BOUNDARY	COMPONENT BOUNDARY


Autelok Option - Diagram SP544a02




Copyright and rights are the property of Johnston Sweepers Ltd.

Littasnatch - Diagram SP545a02

Copyright and rights are the property of Johnston Sweepers Ltd.




Hydrodrive Gearbox - Diagram SP546a02




Copyright and rights are the property of Johnston Sweepers Ltd.

Varagap Option - Diagram SP547a02



Rear Wander Hose - Diagram SP548z00



LEGEND

	8mm OD RED TUBING
	6mm OD RED TUBING
	6mm OD BLUE TUBING
	6mm OD BLACK TUBING
	INTERNAL PILOT LINE
	COMPONENT BOUNDARY




IT IS AN IMPROVEMENT OF THE ORIGINAL DESIGN AND DESIGN IN THIS DRAWING AND DESIGN IS NOT TO BE TAKEN AS A CONTRACT TO ANYTHING IN PARTICULAR FROM JOHNSTON SWEEPERS LIMITED.

REAR WANDERHOSE PNEUMATIC CIRCUIT DIAGRAM


REV. NO.	SP548z00
REV. RANGE	12/2008
REV. NO.	01

Mesh Shaker in Cab - Diagram SP550a02

Copyright and rights are the property of Johnston Sweepers Ltd.



Mesh Shaker - Diagram SP550b02



AUX 2
SP541c02/542a02

PV72

LEGEND

	6mm OD BLACK TUBING
	8mm OD RED TUBING
	6mm OD RED TUBING
	6mm OD BLUE TUBING
	6mm OD BLACK TUBING
	INTERNAL PILOT LINE
	COMPONENT BOUNDARY

Johnston SWEEPERS LIMITED
GRANGE ROAD, DUNDEE, SCOTLAND, DD4 1DF

IT IS AN INSTRUMENT OF THE DRAWING AND DESIGN ITS CONTENTS TO ANY THIRD PARTY WITHOUT THE WRITTEN CONSENT FROM JOHNSTON SWEEPERS LIMITED.

TITLE: PNEUMATIC CIRCUIT
 MESH SHAKERS
 HOPPER CONTROL

PROJECT: 24384-VT/VS
 DRAWN BY: [Signature]
 DATE: 17/08

DOC NO: SP550b02
 REVISION: 01

Copyright and rights are the property of Johnston Sweepers Ltd.



CHAPTER **12**

Wearing Items**Table of Contents**

Section	Page
Replacement Instructions	
Fan Impeller	12 : 2
Intake Duct Flap	12 : 3
Wear Plate	12 : 4
Intake Duct	12 : 4
Intake Trunking	12 : 4
Intake Seat	12 : 5
Nozzle Wheel	12 : 5
Tyre	12 : 5
Wheel Bearings	12 : 6
Nozzle Rubbers	12 : 6
Channel Brush	12 : 6
Wide Sweep Brush Fills	12 : 6

WEARING PARTS REPLACEMENT INSTRUCTIONS

It is important that the following safety precautions are observed when working on the machines.


Safety Precautions


- Ensure the machine is standing on firm, level ground and there are no obstructions above or to the rear before raising the body.
- Ensure the safety prop is engaged at all times when working under the body.
- Ensure operators are fully conversant with the controls and operation.
- Isolate the air in the systems locker before working on any pneumatically operated or controlled equipment.
- Disconnect or isolate the vehicle battery when working on the electrical system.
- Do not approach the fan inlet while the fan is running.
- Do not grasp any part of the engine or exhaust system without first ascertaining whether it has cooled sufficiently to avoid scalding.
- Be aware of the safety instructions relative to the suction fan given in the equipment maintenance notes.
- Keep hands, loose clothing, hair etc. well clear of moving parts.
- Do not climb on the engine walkways unnecessarily or approach the fan inlet whilst the engine is running.
- Do not use ill-fitting tools such as spanners that may slip and cause injury.
- Always get a second person to check periodically that all is well when only one person is working on the machine or inside the body.

*** THESE ITEMS HAVE BEEN SPECIFICALLY DESIGNED FOR LO-NOISE EMISSIONS AND FITTING OF ALTERNATIVE ITEMS COULD CAUSE AN INCREASE IN THE OPERATIONAL NOISE OF THE MACHINE.**

FAN IMPELLER *


INSPECTION -This should be on a regular basis as outlined in the routine maintenance. The impeller should be replaced as soon as the blade thickness is less than 2mm or the blades have visible signs of wear/damage.

REMOVAL

Raise the body and ensure the body prop is engaged in the rack.

Remove the fan case inspection plate. 5 bolts Item 2.

Remove the fan case cover Item 1. 10 bolts.



95MA. 033-2

REMOVAL

Before removing the fan impeller check for any lateral movement in a similar fashion to checking a wheel bearing. An excess of 2mm play would indicate wear in the gearbox bearing and would require overhaul/ replacement.

Remove the 3 bolts under the securing tab washer in the centre of the fan on the VT, or one M12 setscrew/ capscrew on the VS, The fan should slide off the spline - a bearing puller part number 437-2, can be used if required.

REFITTING

Replacement is reverse procedure, taking note of the following.

Lightly grease the fan drive spline, using Klüberpaste JSL part number 94-24, before refitting the impeller.

VT Range:- If setscrews are fitted replace with Tuflock capscrews 148-1 and torque up the three impeller securing bolts to 80 Nm (59 lbf.ft).

VS Range:- If a setscrew is fitted replace with a Tuflock capscrew 148-100 and torque up to 101Nm (75 lbf.ft)

From July 2009 all impellers have a "V" mark, item 6, at Top Dead Centre (TDC) applied when they are manufactured. When fitting a replacement impeller it should be rotated so this mark is at the 12 o'clock (TDC) position before the retaining bolts/bolt are tightened to the prescribed torque.

Refit fan case cover item 1, using sealant part number 94-1, to the mating face having first removed the old sealant. Push the fan assembly towards the drive motor and then pull towards you. If there is excessive play the bearings will require replacement. Adjust the three transition adjustment nuts, item 4, to give a gap between the transition ring and impeller of 3-4mm for a full 360 degrees as shown in figure opposite.

Refit the fan case inspection plate item 2, using sealant as for item 1.


An inspection plate, item 7, is provided to measure the fan speed by optical tachometer if required.

INTAKE DUCT FLAP

When the flap plate is in the open position, it is abraded by the material discharging from the intake duct into the body. The flap should be inspected periodically and replaced when worn. To inspect one must first open the rear door and suitably prop open, then depressurise the air system in the systems locker, this will allow the flap to be opened and closed manually from the interior of the body. Enter body and inspect the flap valve plate which is secured to actuating fingers by a pair of spring clips.

REMOVAL


To remove a flap plate the springs must be withdrawn using a suitable tool or bar. Notice how the springs were fitted from each side of the finger guide and around the groove in the finger assembly. Once the springs are removed the flap plate can be detached from the finger.

**REFITTING**

Before refitting or fitting a new flap plate, ensure the springs are in good condition and the finger adjustment areas have been cleaned, then locate flap on the finger and replace springs. Ensure the flap plate seats correctly on top of the inlet tube, if not, check for excessive wear on the inlet tube/flap, or adjustment of the flap operating mechanism.

WEAR PLATE
REMOVAL

Enter the body after carrying out precautions as for intake duct flap. The wear plate (A) is secured by two screws and a clamp bar (B). It is a wise precaution to prop the wear plate before attempting to remove these screws. Once the screws are removed, support the wear plate and remove the prop. Allow the wear plate to fall slightly and unhook from the hooks (C) attached to the body outer skin, and remove. Help may be required in removal as this unit weighs approximately 36kg.




95MA.005

INTAKE DUCT

These parts are also abraded by the material being conveyed from the suction nozzle and must be periodically inspected and replaced when worn or holed. The duct is 250mm diameter.

REMOVAL

Enter body after carrying out the same precautions as for intake flap replacement. Remove the four bolts securing the collar (A) around the intake duct (B). Lift up the flap manually (if fitted) and remove collar. A rubber cord (C) will now be visible which should also be removed with care to prevent damage. Dismount from body. Tip body and support on prop. Remove the four bolts in the square flange carrying the flexible trunking seat seal (D). The intake duct can now be pulled downwards clear of the body.



95MA.006

REFITTING

Reverse of removal procedure, but if fitting a new duct a new trunking seat seal should be used and secured using a contact adhesive, Part No. 9903. Fit two bolts in diagonal holes, the duct (B) has two holes with keyhole slots. Align slots over the bolt heads and twist. Fit the other two bolts and tighten. The rest is the reverse of the removal instructions. Replace the rubber cord (C) and collar plate (A) inside the body and secure. Finally, fully tighten the four duct top retaining bolts.

NB. Torque for brass M12 bolts 22 Nm (25ftlbf).

FLEXIBLE INTAKE TRUNKING *
REMOVAL

Lower suction nozzle to the ground, release worm drive clips at either end and remove trunking. The nozzle trunking has an inside diameter of 250mm.

REFITTING

Loosely fit worm drive clips to either end of trunking. Engage trunking onto the nozzle with a 55mm (2") overlap and tighten clip. Fit other end to the intake seat and secure. Check trunking is not twisted or rucked and does not foul anything when the nozzle is raised or lowered again.

INTAKE SEAT


REMOVAL

Firstly tip body and support on prop. Release trunking from tube as described on previous page. Release and remove the three countersunk screws and nuts (A). Lift seat (B) clear of bracket.

REFITTING


Reverse of removal procedure. As no adjustment for seal compression is provided, it is wise to check seal compression when the body is lowered.

Note : When replacing the intake seat, it is important that the correct length is used. The correct length of intake seat is determined by measuring dimension A, as shown below, from ground to underside of the subframe (i.e. top of chassis).



95MA.007

Dimension A	Inlet Seat Part No. 'B'
900 - 999	94990-1
1000 - 1099	94990-3
1100 - 1199	94990-4



95MA.008

SUCTION NOZZLE WHEEL

REMOVAL

Release nozzle wheel adjustment nut (A) on inner end of wheel spindle. Remove wheel complete.


REFITTING

Reverse of removal procedure.

TYRE - SUCTION NOZZLE WHEEL

REMOVAL

Remove nozzle wheel as above. Remove five screws securing tyre plate (B) and prise off. Remove tyre from hub.



M.0012

REFITTING

Reverse of removal procedure.

Note : Ensure correct re-setting of nozzle rubbers in relation to the ground.

NOZZLE WHEEL BEARINGS**REMOVAL**

To withdraw bearing remove wheel assembly from carriage and remove the three setscrews from the retaining plate. Refit washer and nut, insert M6c x 50mm setscrews, Part No. 124-113, in the three unused retainer plate holes. Tighten each bolt half a turn at a time to extract the bearing. Remove drift bearing from shaft.

REFITTING

Reverse of removal procedures.

SUCTION NOZZLE RUBBERS**REMOVAL**

This can be effected without removing the nozzle assembly from the machine but if personnel are inexperienced it will probably be easier to remove nozzle assembly and turn upside down. Release two screws retaining bump bar at kerb end of nozzle. Release securing nuts retaining the rubbers. Pull away the two short end rubbers, then remove the front and rear side rubbers.

REFITTING

Reverse of removal procedure remembering to fit the radius rubber to the nozzle rear. Do not over tighten the nuts as this will cause distortion of the rubber. Refit bump bar.

CHANNEL BRUSH

Sharp objects

REMOVAL

It is preferable to have brush in working position with auxiliary engine stopped. Release four nuts from coach bolts securing brush stock assembly drive plate. Remove brush.

REFITTING

Reverse of removal procedure. Any loops of steel tines which project above the head of the stock should be hammered flush before offering up brush stock assembly to driving plate.

WIDE SWEEP BRUSH CORE ASSEMBLY


Sharp objects

See Chapter 6 in the Operator's Guide.

WIDE SWEEP BRUSH FILLS

There are two types of brush fills:

- Replacement segments
- Plastic 'throw away' stock tines.

Replaceable Segments

95MA. 034-2

REMOVAL

Release and remove the retaining screws (F) securing the end plate / adaptor (A). Slide off the segments (B) and spacers (C) from the central core. **Note** : On earlier machines the driving pin (E) on the inner diameter of the segments must be aligned with a slot (D) on the core (G) where the two parts join.


REFITTING

First slide on a segment then alternately a spacer and a segment. Sufficient spacers and segments must be fitted to allow the end plate to nearly abut with the core and also clamp them tightly. The peg (E) on the segment (B) to be alternatively located round the core clockface at 12, 2, 4 o'clock and so on until the core is filled, failure to observe this could cause the brush to bounce. The last segment must have the pin (E) on the segment (B) located in the cutout (D) to ensure the peg does not interfere when the parts are bolted together.

Note : Lightly smear the retaining screws (F) with grease with grease.

This assembly is designed to accommodate 406mm diameter segments.

Plastic Throw Away Stock



The stock (H) is removed and can be recycled as plastic waste.

CHAPTER

13**Remove and Refit Procedures****Table of Contents**

Section		Pages
Removal and Refitting Instructions		
Water Pump	VT & VS	13 : 2
Wide Sweep Brush Motor	VT & VS	13 : 3
Channel Brush Motor	VT & VS	13 : 3
Channel Brush Cylinder	VT & VS	13 : 4
Hydrodrive Gearbox & Pumps	VS Only	13 : 5
Fan Drive Motor	VS Only	13 : 5
Radiator	VT Only	13 : 6
Hydraulic Pump	VT Only	13 : 6
Fan Impeller	VT Only	13 : 6
Fan Case	VT Only	13 : 6 & 8
Gearbox	VT Only	13 : 7 & 8
Fluid Drive Coupling	VT Only	13 : 7 & 8
Flywheel	VT Only	13 : 7

This section describes the removal and refitting of some of the major components on the machine. These are not routine jobs and should normally only need to be undertaken when overhauling or exchanging these units.



Safety Precautions




The hinged prop stowed beneath the body **SHOULD BE USED AT ALL TIMES** to prop the body when carrying out any inspection, servicing or maintenance work beneath the body.

Disconnect the battery negative lead before undertaking any of the following operations on the auxiliary pack.

1. WATER PUMP - DUST SUPPRESSION - Removal and refitting

- 1 Isolate the water supply at the filter unit.
- 2 Disconnect the feed and pressure water pipes (A) to the pump.
- 3 Remove the 4 bolts (B) holding the water pump to the drive motor.
- 4 Withdraw the pump assembly from the drive coupling (C).
- 5 Refitting is the reverse procedure, ensure that the pump drive gear does not bottom in the drive coupling.

NB It is possible to replace the pump diaphragms and valves with the pump in situ.



M. 0061

2. WIDE SWEEP BRUSH MOTOR - Removal and Refitting

- 1 Remove the brush stock as described in Chapter 6.
- 2 Unscrew the four end plate securing setscrews and remove plate complete with motor assembly and drive shaft or drive dog.





FIGURE 4 - WIDE SWEEP BRUSH MOTOR

- 1 End plate securing screws.
- 2 Drive shaft retaining screws.
- 3 Drive shaft/drive dog.
- 4 -
- 5 Drive adaptor retaining screw.
- 6 Drive adaptor
- 7 Motor securing screws


3. CHANNEL BRUSH MOTOR - Removal and refitting



1. Unscrew the four nuts (A) from the coach bolts securing the channel brush to the drive adaptor plate and remove brush.
2. Unscrew the retention screw (B) from the centre of the drive adaptor plate and remove plate.
3. Disconnect the two hydraulic hoses from the motor.
4. Unscrew the two bolts securing the motor to mounting bracket and lift off motor.
5. Refitting is the reverse of removal.

4. CHANNEL BRUSH CYLINDER - Removal and refitting

1. Disconnect the two hydraulic hoses from rear of the cylinder.
2. Remove cylinder pin (B).
3. Remove stop from pivot frame (D).
4. Remove cylinder eye pivot (E) from pivot head lever (F). Lift out cylinder.
5. Refitting is the reverse of removal, grease items (B) and (E) prior to refitting.




M. 0054-2

5. LIFTING OR REMOVAL OF THE BODY

If it is necessary to raise the body, two holes are provided in the front of the body.

- Remove blanking bolts (A).
- Insert eye bolt item (B) part no. 442-1 into the M16 socket.

If the body has to be removed use the two lifting eyes and point (C) with a suitable chain or web strap.



95EM. 002-2

10. HYDROSTATIC GEARBOX AND PUMPS


The individual pumps may be removed in situ if required. However, the following criteria applies.

On the end of the transmission pump (identified by an oil filter mounted on the side of the pump) is mounted the sweep gear drive pump.

The fan drive pump is mounted on the opposite side of the gearbox to the transmission pump (i.e. front to rear). On the end of the fan drive pump is mounted an option pump to drive supawash or other accessories.

The transmission drive motor(s) are always mounted on the opposite side of the gearbox to the transmission pump.

If the removal of any pump is required, it is first necessary to minimise oil loss by loosening the cap on the hydraulic return filter.




Care should be taken as the oil may be under pressure if the vehicle has just stopped, and the cap loosened slowly.

All hoses should be plugged after the removal of any pump to prevent dirt ingress and oil loss from the hoses.

HYDRODRIVE GEARBOX


The hydrodrive gearbox and pump assemblies can be removed as a complete unit by using a lifting jig, Part No 93828-1.



If the gearbox is to be removed, the truck will be immobile. The ignition keys should be removed to prevent inadvertent starting and consequential damage to the drive line and components.

11. FAN DRIVE MOTOR - Removal and refitting

- 1 Remove fan case cover and impeller as described earlier.
- 2 Loosen cap on hydraulic return filter.
- 3 Disconnect hydraulic hoses from ports A, B, C and D.
- 4 Remove 4 setscrews (E) holding motor on to the mount.
- 5 Withdraw motor.
- 6 Refitting is the reverse procedure to removal. Lubricate motor drive shaft with Molykote DX (Part No 30-100) before refitting.
- 7 Motor securing capscrew should be tightened to torque of 101 Nm.
- 8 Retighten cap on hydraulic return filter.



M. 0060

20. RADIATOR - Removal and Refitting

- 1 Remove lower hose from water pump and direct flow of coolant into a suitable container.
- 2 Remove top hose from radiator.
- 3 Unscrew the five button headed socket screws and remove walkway in front of radiator.
- 4 Unscrew the four mounting screws and withdraw radiator from shroud.
- 5 Refitting is reverse of removal, but fit lower two mounting screws first to allow radiator to pivot making the lower hose fitment easier. Refill cooling system with specified anti-freeze mixture.

21. HYDRAULIC PUMP - Removal and Refitting

- 1 Remove both low and high pressure pipes from pump.
- 2 Remove the setscrews from the pump flange to timing case and remove pump.
NB : Iveco engine has a pump drive adaptor.
- 3 Refitting is the reverse of removal. Apply a little grease, not sealant, to mating surfaces and fit a new gasket. Torque gear securing nut to 27 lbf/ft (50 Nm)(Perkins).

22. FAN IMPELLER - Removal

Before removing the fan impeller check for any lateral movement in a similar fashion to checking a wheel bearing. Any excessive play would indicate wear in the bearing/gearbox assembly and would require an overhaul.

- 1 Unscrew the ten fan case cover securing setscrews and remove cover (see chapter 2).
- 2 Unscrew the three impeller securing setscrews having first straightened the tab washer.
- 3 Withdraw the impeller from the splined shaft, Puller, Part No. 437-2, is available for this purpose (if required). Lift fan from case.

23. FAN CASE - Removal

- 1 Carry out procedure 22.
- 2 Remove the screws (B) holding the mask plate onto the gearbox and remove the mask.
- 3 Disconnect the silencer assembly at the flexible joint on the exhaust manifold.
- 4 Unscrew the four setscrews (two per side) holding the fan case to the front and rear valances.
- 5 Unscrew the two button head socket screws, one at each end of walkway together with the two setscrews 5a.
- 6 Unscrew the two lower setscrews (5a) securing the fuel tank to front and rear valances. Loosen the two upper setscrews each side (5b) in the elongated holes allowing the tank to slide outwards. Lift out fan case.




FIGURE 1 - FAN CASE
(Procedures 22 and 23)

- (1) Rubber diaphragm.
- (2) Mask and special securing screws.
- (3) Fan case securing screws.
- (4) Button headed screws.
- (5) Fuel tank securing screws.
- (a) remove
- (b) loosen

24. GEARBOX - Removal

- 1 Carry out procedures 22 and 23.
- 2 Drain fluid drive coupling as described in Chapter 7.
- 3 Remove the six setscrews securing the gearbox to the bell housing and the four bolts holding the two cover plates to the flywheel housing.
- 4 Withdraw the gearbox, supporting its weight so as not to damage the input shaft fluid drive coupling.
- 5 On some installations there may be an adaptor ring between gearbox and flywheel housing.

25. FLUID DRIVE COUPLING - Removal

- 1 Carry out procedures 22, 23 and 24.
- 2 Remove the twenty socket head screws securing the coupling to the flywheel.
- 3 Insert M8 setscrews in the two blind extractor holes and tighten each half a turn at a time to ease the coupling from the flywheel.




FIGURE 2 - FLUID DRIVE COUPLING AND FLYWHEEL
(Procedures 7 to 10)

- 1 Fluid coupling.
- 2 Flywheel.
- 3 Bell housing.
- 4 Gearbox.
- 5 Gearbox input shaft.
- 6 Rubber cover if fitted. Part No. 221-3.
- 7 Gearbox support bearing.
- 8 Oil seal, Part No. 77-39.
- 9 'O' ring, Part No. 656-2.
- 10 'O' ring, Part No. 656-1.
- 11 Adaptor ring.

26. FLYWHEEL - Removal

- 1 Carry out procedures 22, 23, 24 and 25.
- 2 On Perkins engines only - pierce and prise out rubber covers from retaining bolts.
- 3 Remove setscrews and withdraw the flywheel.

27. FLYWHEEL - Refitting

- 1 On Iveco and John Deere units apply Loctite 510 between the crankshaft palm and the flywheel around the mounting holes. Also apply Loctite 275 onto the fixing bolts.
- 2 Refit flywheel and torque retaining setscrews to 138 Nm on Iveco and John Deere units and 108 Nm on Perkins units.
- 3 On Perkins engines only - fit new retaining screw covers flush with flywheel, having ensured the screw heads and flywheel undercuts are clean and oil free. Leave 10-15 minutes then check covers have not pushed out, tap in if they have.
- 4 Replace the support bearing in the centre of the flywheel.

28. FLUID DRIVE COUPLING - Refitting

- 1 Before fitting coupling, renew oil seal and 'O' rings (Items 8, 9 and 10, Figure 2).
- 2 Generously grease both 'O' rings and internal splines with Kluber Paste 46MR401, JSL Part No. 94-24.
- 3 Offer fluid drive to the flywheel ensuring bolt holes are in line. Push assembly together by hand, making sure not to trap and damage the large 'O' ring.
- 4 Refit the ring of M8 cap screws and tighten to a torque of 26 Nm (19 lbf.ft) on Perkins and Iveco engines.

NB : On the John Deere engines the cap screws are M6 and torqued up to 19 Nm (14 lbf.ft)

29. GEARBOX - Refitting

- 1 Lightly grease splines on the input shaft with Kluber Paste, JSL Part No. 94-24.
- 2 Some engine installations have an adaptor ring between the flywheel housing and the gearbox. (See Fig. 2, Item 11)
- 3 Ease the gearbox onto the engine bell housing whilst rotating the output shaft. Use the securing setscrews to finally pull the gearbox up to the housing.
- 4 Ensure the output shaft rotates freely after assembly.
- 5 Refit the two side cover plates.
- 6 At this point it is advisable to refill the fluid coupling and gearbox (if it has been drained) as described in Chapter 7 of this manual.

30. FAN CASE - Refitting

Refitting is the reverse of removal described in Chapter 12, but when refitting the mask to the gearbox, ensure it abuts or is very close to the rubber diaphragm attached to the fan case. Apply stud lock to the mask retaining screws before fitting.

31. FAN IMPELLER - Refitting

See Chapter 12.

32. FAN CASE COVER - Refitting

See Chapter 12.

CHAPTER

14**Fault Diagnosis****Table of Contents**

Section		Page
Power Systems		
Hydraulic	VT & VS	14 : 2
Pneumatic	VT & VS	14 : 2
Water	VT & VS	14 : 2
Electrical	VT & VS	14 : 3
Suction System		
Suction System	VT & VS	14 : 4
Power Pack		
Auxiliary Engine	VT Only	14 : 5
Electrics and Shut Down System	VT Only	14 : 5
Sweep Gear		
Wide Sweep Brush	VT & VS	14 : 6
Channel Brush	VT & VS	14 : 7
Maxigap Nozzle	VT & VS	14 : 7
Discharge		
Body Tip	VT & VS	14 : 8
Hydrodrive	VS Only	14 : 9

HYDRAULIC SYSTEMS

FAULT SYMPTOM	POSSIBLE CAUSE
Hydraulic oil frothing	<ol style="list-style-type: none"> 1. Air getting into system. Check LP pipe to pump. 2. Defective pump shaft seal. 3. Wide sweep brush lift cylinder seals defective. 4. Return pipe separated from underside of return filter inside hydraulic tank.
Sluggish hydraulics	<ol style="list-style-type: none"> 1. Cartridge valve not travelling full extent - measure oil flow. 2. Blocked filters. 3. Air in oil

PNEUMATIC SYSTEMS

FAULT SYMPTOM	POSSIBLE CAUSE
Low pressure warning buzzer on continuously	<ol style="list-style-type: none"> 1. Air pressure switch faulty. 2. Insufficient pressure in Johnston system.
Constant air leak from solenoid block	<ol style="list-style-type: none"> 1. Cylinder seals leaking internally. 2. Air solenoid faulty.

WATER SYSTEMS

FAULT SYMPTOM	POSSIBLE CAUSE
Jet continuously leaking	<ol style="list-style-type: none"> 1. Grit under armature seating. 2. Armature stuck open. 3. Manual override on.
No water to wash down hose or jets	<ol style="list-style-type: none"> 1. Water pump filter blocked. 2. Water tank filter blocked. 3. Water pump belt loose or broken. 4. Drain tap on filter open. 5. Filter isolation valve closed. 6. Filter assembled incorrectly 7. Pump valves fitted incorrectly after overhaul.
Lack of pressure	<ol style="list-style-type: none"> 1. Grit under relief valve seating. 2. Relief valve spring broken. 3. Relief valve stuck open. 4. Relief valve worn.

ELECTRICAL SYSTEM

FAULT SYMPTOM	POSSIBLE CAUSE
Beacon not working	<ol style="list-style-type: none"> 1. Check vehicle ignition is on 2. Check beacon bulb/motor 3. Check feed to beacon 4. Check earth wire 5. Check fuse No. 1 for front. Fuse 2 for rear 6. Check switches
Work lights not working	<ol style="list-style-type: none"> 1. Check vehicle ignition is on, master switch V is illuminated 2. Check bulb 3. Check feed to light 4. Check earth wire 5. Check fuse No. 1 6. Check switch
Flap (duals) fail to operate	<ol style="list-style-type: none"> 1. Check feed to solenoid/Plug LED's V11 or V12 2. Check solenoid 3. Check earth wires 4. Check fuse No. 4 5. Check switch
Nozzle pneumatic solenoids fail to operate	<ol style="list-style-type: none"> 1. Check feed to solenoid/Plug LED V2 or V10 2. Check solenoid 3. Check earth wires 4. Check fuse No. 4 5. Check switch
Channel Brush fails to lower	<ol style="list-style-type: none"> 1. Check feed to solenoid/Plug LED V4 or V10 2. Check solenoid 3. Check earth wires 4. Check fuse No. 4 5. Check switch
Channel Brush fails to rotate	<ol style="list-style-type: none"> 1. Check feed to solenoids/Plug LED (see Modus Operandi) 2. Check solenoid 3. Check earth wire 4. Check fuse No. 4 5. Check switch
Channel Brush water fails to operate	<ol style="list-style-type: none"> 1. Check feed to solenoid/Plug LED's W03/W08 2. Check solenoid for operation/obstruction 3. Check earth wire 4. Check fuse No. 4 5. Check Wide Sweep Brush hydraulic
Wide Sweep Brush fails to lower	<ol style="list-style-type: none"> 1. Check feed to solenoids/Plug LED's V4 2. Check solenoid 3. Check earth wire 4. Check fuse No. 5 5. Check switch
Wide Sweep Brush fails to rotate	<ol style="list-style-type: none"> 1. Check feed to solenoid/Plug LED (see Modus Operandi) 2. Check coil for operation 3. Check earth wire 4. Check fuse No. 5 5. Check switch
Wide Sweep Brush water solenoid fails to operate	<ol style="list-style-type: none"> 1. Check feed to solenoid/Plug LED W01 2. Check solenoid for operation/obstruction 3. Check earth wire 4. Check fuse No. 5 5. Check switch

Copyright and rights are the property of Johnston Sweepers Ltd.

SUCTION SYSTEM

FAULT SYMPTOM	POSSIBLE CAUSE
No pickup performance	1. Hopper full, causing airflow to be throttled: - Discharge load.
	2. Nozzle or nozzle trunking blocked or restricted by debris.
	Check the nozzle water jets are not blocked, are working correctly and lubricating the intake duct.
Poor pickup performance	3. Intake flap not open (dual m/c's). Blanking plate not removed after using the wanderhose (single m/c).
	1. Maxigap nozzle not set to the optimum opening., i.e. too close to ground
	2. Nozzle trunking partially restricted by debris. Check nozzle water jets are working correctly and so lubricating the duct.
	3. Channel brush incorrectly set, not directing debris in line with nozzle.
	4. Intake flap not fully opened (dual m/c's).
	5. Rear body meshes blocked or restricted.
	6. Fan case transition ring not correctly set.
	7. Fan flap incorrectly set or is incapable of attaining correct opening due to damaged relay mechanism.
	8. Low oil level in fluid flywheel.
	9. Air silencer pack in roof of cowl blocked with debris and/or sound absorbent material separating from its substrate causing a restriction.
	10. Fan case inlet make and break seal fitted to flanged duct on body front face either degraded and not sealing or missing. Note: The fan case outlet seal, unlike the inlet seal, has no effect on air performance and only provides the function of a dust seal.
11. Engine is not running at correct operational speeds. Check fuel filter or air filter blocked/ causing a restriction.	

AUXILIARY ENGINE

FAULT SYMPTOM	POSSIBLE CAUSE
Auxiliary engine fails to turn over	<ol style="list-style-type: none"> 1. Check truck ignition is on 2. Check battery and connections 3. Check ignition switch 4. Check starter motor
Auxiliary engine starts but will not accelerate	<ol style="list-style-type: none"> 1. Check throttle cable is not broken/jammed 2. Check feed to actuator 3. Check fuse No. 8 4. Check switch
Auxiliary engine turns over but will not start	<ol style="list-style-type: none"> 1. Check fuel tank 2. Check electric feed to engine injector shut off fuse 8 3. Check injector shut off valve 4. Check fuel lines for loose connections 5. Check oil pressure sender and connections 6. Check water temperature sender 7. Bleed fuel system
Auxiliary engine runs but stops after 8 seconds	<ol style="list-style-type: none"> 1. Check engine oil pressure is above 0.5 bar 2. Oil pressure switch faulty (Not Iveco engine)

AUXILIARY ENGINE ELECTRICS AND SHUT DOWN SYSTEM

FAULT SYMPTOMS	POSSIBLE CAUSE
Oil pressure warning light not illuminated when ignition on engine stopped (Not Iveco E3)	<ol style="list-style-type: none"> 1. Check fuse No. 9 2. Check feed to oil pressure switch 3. Check earth wire 4. Check bulb.
Water temperature warning light illuminated (Not Iveco E3)	<ol style="list-style-type: none"> 1. Unit overheated 2. Low coolant level 3. Blocked radiator 4. Check temp. sender if engine fails to shut down
ESOS electric failure (Not Iveco E3)	<ol style="list-style-type: none"> 1. Check fuse No. 8 2. Check oil pressure switch 3. Check water temperature switch 4. Check feeds to ESOS 5. Check ESOS valve

Copyright and rights are the property of Johnston Sweepers Ltd.

WIDE SWEEP BRUSH

FAULT SYMPTOM	POSSIBLE CAUSE
Not rotating	<ol style="list-style-type: none"> 1. Worn drive adaptor and plate 2. Bearings seized 3. Motor seized 4. Foreign matter jammed in brush. 5. Check electrical feed to solenoid/Plug LED (see Modus Operandi) 6. Check hydraulic system for pressures for diagnosis of problem
Rotating slowly	<ol style="list-style-type: none"> 1. Motor worn 2. Hydraulic pump worn 3. Brush end bearing seized
Bouncing	<ol style="list-style-type: none"> 1. Regulator adjustment incorrect 2. Brush stock bent 3. Linkage pins/brackets worn/damaged 4. Air damping system not working
Not dropping	<ol style="list-style-type: none"> 1. Check feed to solenoid/Plug LED V4 2. Solenoid faulty 3. Switch on control box faulty 4. Linkage/pivots/cylinders seized
Lifts intermittently	<ol style="list-style-type: none"> 1. Faulty or loose electrical connections while in working mode
Air leaking from Wide Sweep Brush	<ol style="list-style-type: none"> 1. Shuttle valve or regulator defective 2. Lift ram seals worn
Brush not slewing - dual sweep machines	<ol style="list-style-type: none"> 1. Check slew cylinder for damage/corrosion 2. Solenoids B1 B2 not operating

CHANNEL BRUSH

FAULT SYMPTOM	POSSIBLE CAUSE
Brush slows down after	<ol style="list-style-type: none"> 1. Hydraulic pump worn 2. Channel brush worn 3. Check hydraulic pressure for fault diagnosis
Works intermittently	<ol style="list-style-type: none"> 1. Check switch in Control Panel and looms for loose connections
Brush fails to lift	<ol style="list-style-type: none"> 1. Check for electrical power at solenoid/Plug LED V5 or V6 if a dual. 2. Check pneumatic solenoid for correct operation 3. Seals in cylinder leaking

MAXIGAP NOZZLE

FAULT SYMPTOM	POSSIBLE CAUSE
Maxigap will not tilt	<ol style="list-style-type: none"> 1. Check feed to pneumatic solenoid/Plug LED V1 or V9 if a dual. 2. Pneumatic solenoid valve faulty. 3. Cylinder pivot/linkage seized.

Copyright and rights are the property of Johnston Sweepers Ltd.

BODY TIP**FAULT SYMPTOM****POSSIBLE CAUSE**

Rear door will not open

1. Check handbrake is on
2. Check master switch V is illuminated
3. Check green safety run button is pressed on pedant unit
4. Check pendant unit has not become unplugged

Body will not tip

1. Ensure handbrake is on
2. Ensure master switch V is on (illuminated)
3. Check feed to solenoids/Plug LED
4. Check green safety run button is pressed on pedant unit
5. Check pendant unit has not become unplugged

HYDRODRIVE GEARBOX SYSTEM

FAULT SYMPTOM	POSSIBLE CAUSE
No forward/reverse drive	<ol style="list-style-type: none">1. Is truck chassis in 1:1 gear.2. On dual sweep m/c has drive for power steering changeover been correctly selected3. Is master switch V1 illuminated4. Has engine rpm increased from tickover to 1,1005. Check boost pressure on transmission pump is 24 bar.6. If fan/sweep gear operates check feed at Mills plug on transmission pump. The voltage at pins A and B should be 0-2.5 volts dependant upon pedal position. If okay, refit plug ensuring it is screwed fully home. If no voltage, call for service assistance.

Copyright and rights are the property of Johnston Sweepers Ltd.

CHAPTER

15**Service Tools****Table of Contents**

Section		Page
Service Tools		
Service Tools	VT & VS	15 : 2
Microprocessor Controller	VS Only	15 : 3
Hydrodrive Transmission	VS Only	15 : 11

The following tools are available through our Spares Network

	TOOL NO	ITEM	FUNCTION
>	283266-1	ESU Unpacking Control Unit	Rear door control (single plug) to enable ESU's to be unpacked
	437-2	Bearing Puller	Removal of fan impeller bearings etc
	437-3	Pressure Gauge Set	Measure hydraulic, pneumatic and water pressures
	437-4	Optical Tachometer	Measure fan rpm
	437-7	0-55 Litres/Min Flow Gauge	Hydraulic flows
	437-8	Impulse Adaptor	Connects to 437-4 to measure engine speeds from fuel injection pipes
	437-9	D-TEC Programme (PPU)	For calibration on D-TEC Units
	437-11	Check valve insertion tool	To fit check valve 421-278
	437-311	Nylon Tube Cutter	Ø5 - Ø6mm
	TN 7964	Torque Wrench Extension Spanner	Fits special bolts 62077-1 on WS Brush Compensator Shaft
	93828-1	Hydrodrive Gearbox-Lift Jig	Removal of hydrodrive gearbox and pump assemblies by a cradle to fit a trolley lift jack.
	422-1	Body Eye Bolt	Raising/lifting of body
	201208-1	Workshop Body Prop	Used when replacing a damaged body prop
	283306-1	Pocket	Used when replacing a damaged body prop

Copyright and rights are the property of Johnston Sweepers Ltd.

D-Tec

MICROPROCESSOR CONTROLLER

***Set-Up and Commissioning Procedure
For
Truck Mounted Units***

***D-Tec Version 04 Onwards Software
employing Sauer Sundstrand Hydrostatic
Transmission Components***

1 - INTRODUCTION

The purpose of this Chapter is to provide specific data and instruction for setting-up and commissioning the **D-Tec** microprocessor controller on a Johnston truck chassis based sweeper with the Johnston HydroDrive hydrostatic transmission employing Sauer Sundstrand equipment. The data is also specific to the **D-Tec** software version 04 onwards. The **D-Tec** controller is factory pre-programmed with a set of parameters which are optimised to allow a first-time start-up. A list of these parameters and their values are shown on the 'log sheet' on the next page of this chapter.

Unfortunately, due to mechanical and electrical control tolerances within the hydrostatic pump, the foot pedal control, it is necessary to ascertain and adjust six specific physical parameter adjustments which have an effect on the way the controller performs. These six parameters are:-

- A2 - Pulses per rev** (number of pulses from the speed sensor per engine revolution)
- A4 - Calibrate the throttle** (programme injector pump movement)
- B5 - Min. pedal posn** (foot pedal position relaxed)
- C5 - Max. pedal posn** (foot pedal position deflected)
- C2 - Minimum current** (minimum current applied to the transmission system)
- B7 - Maximum current work forward** (maximum current applied to the transmission system)
- B8 - Maximum current work reverse**

The log sheet example which is included in the booklet shows two numerically valued columns, one with all the factory set pre-programmed default parameter values for the VS Range. In the second column it provides spaces for recording the actual set values which will be determined by following the instructions in setting-up the five variable parameters described above. Log sheets should be retained for each machine with its service records.

Please note that all parameters shown in **bold script** on the log sheet should be maintained and not varied from. It is prudent to check that these bold values have been correctly programmed as variations have occurred on occasion.

Currently two D-Tec models are used, i.e. Z910 and Z918. See Section 3 of this chapter for identification of model.

NB : On chassis with electronic fuel injection, the engine management system will have been employed and therefore some parameters will have been reset to allow it to function within our specifications.

A copy of this setting information can be obtained from our Service Department on quotation of the machine serial number - EQ

JOHNSTON D-Tec Microprocessor Controller

LOG SHEET - Programmer Parameter Setting For Z910

MACHINE TYPE:

D-Tec Serial No:	Date:	Special features:
Actuator Serial No:	Datalogger calibration No:	
Calibrated by:	EQ No:	

PROGRAMMER SWITCH		FACTORY PRE-PROGRAMMED VALUES		ACTUAL ADJUSTED VALUES			
POS	FUNCTION	IGN	ENG	IGNITION ONLY		ENGINE RUN	
A1	Model Number	910	*	910		*	
A2	Pulses per rev.	06	*			*	
A3	*Actuator %	00		Min.	Max.	Min.	Max.
A4	Calibrate push up					*	
A5	*Pedal position	00		Min.		Max.	
A6	*Hand Thrt position (if fitted)	00		Min.		Max.	
A7	(not implemented)	00				00	
A8	(not implemented)	00				00	
A9	(not implemented)	00				00	
A10	(not implemented)	00				00	
A11	(not implemented)	00				00	
A12	(not implemented)	00				00	
A13	(not implemented)	00				00	
A14	(not implemented)	00				00	
A15	(not implemented)	00				00	
A16	(not implemented)	00				00	
B1	Gain	10				10	
B2	Zeta	265				265	
B3	Window +/- (RPM)	05				05	
B4	(not implemented)	00				00	
B5	Pedal Min. (see A5+23)	25					
B6	Hand Thrt. Min (if fitted see A6+23)	25					
B7	Max. Cur. FW mA (120 max)	100					
B8	Max. Cur. RW mA (120 max)	100					
B9	Max. Cruise	50				50	
B10	Max. Work (RPM)	1700				1700	
B11	Min. Work (RPM)	1100				1100	
B12	Speed up/ dn Rate	242				242	
B13	Ramp up FW	25				25	
B14	Ramp up RW	25				25	
B15	Ramp down FW	05				05	
B16	Ramp down RW	05				05	
C1	(not implemented)	00				00	
C2	Min. Cur. MA	3				3	
C3	*Switch inputs +	N/A				*	
C4	*Switch inputs -	N/A				*	
C5	Pedal Max. (see A5-5)	210					
C6	Hand Thrt Max.(if fitted see A6-5)	210					
C7	Thrt before Lug%	75				75	
C8	(not implemented)	00				00	
C9	(not implemented)	00				00	
C10	Lug Start W	100				100	
C11	Lug End W	500				500	
C12	Lug Ramp up T & W	50				50	
C13	Lug Ramp dn T & W	50				50	
C14	(not implemented)	00				00	
C15	*Software version	*T04				*T04	
C16	*Hours work	00				*	
	*Hours total					*	

* = Read Only Function

Not used on Software T04

SOFTWARE VERSION T04 Rev 02

PJP/08/03/01

Issue 04

Copyright and rights are the property of Johnston Sweepers Ltd.

JOHNSTON D-Tec Microprocessor Controller

LOG SHEET - Programmer Parameter Setting For Z918

MACHINE TYPE:

D-Tec Serial No:	Date:	Special features:
P-Pak Serial No:	Datalogger calibration No:	
Calibrated by:	EQ No:	

PROGRAMMER SWITCH			FACTORY PRE-PROGRAMMED VALUES		ACTUAL ADJUSTED VALUES			
POS	FUNCTION		IGN	ENG	IGNITION ONLY		ENGINE RUN	
	IGNITION ONLY	ENGINE RUN						
A1	Model Number	*Tacho. (RPM)	918	*	918		*	
A2	Pulses per rev.	*Target speed.	06	*			*	
A3	*Injector pump %		*00		Min.	Max.	Min.	Max.
A4	*Valve Cur mA						*	
A5	*Pedal position		*00		Min.		Max.	
A6	*Hand Thrt position (if fitted)		*00		Min.		Max.	
A7	<i>(not implemented)</i>		00				00	
A8	<i>(not implemented)</i>		00				00	
A9	<i>(not implemented)</i>		00				00	
A10	<i>(not implemented)</i>		00				00	
A11	<i>(not implemented)</i>		00				00	
A12	<i>(not implemented)</i>		00				00	
A13	<i>(not implemented)</i>		00				00	
A14	<i>(not implemented)</i>		00				00	
A15	<i>(not implemented)</i>		00				00	
A16	<i>(not implemented)</i>		00				00	
B1	Gain		10				10	
B2	Zeta		265				265	
B3	Window +/- (RPM)		05				05	
B4	<i>(not implemented)</i>		00				00	
B5	Pedal Min. (see A5+23)		25					
B6	Hand Thrt. Min (if fitted see A6+23)		25					
B7	Max. Cur. FW mA (120 max)		100					
B8	Max. Cur. RW mA (120 max)		100					
B9	Max. Cruise		50				50	
B10	Max. Work (RPM)		800				800	
B11	Min. Work (RPM)		800				800	
B12	Speed up/ dn Rate		242				242	
B13	Ramp up FW		25				25	
B14	Ramp up RW		25				25	
B15	Ramp down FW		05				05	
B16	Ramp down RW		05				05	
C1	<i>(not implemented)</i>		00				00	
C2	Min. Cur. MA		3				3	
C3	*Switch inputs +		N/A		*			
C4	*Switch inputs -		N/A		*			
C5	Pedal Max. (see A5-5)		210					
C6	Hand Thrt Max.(if fitted see A6-5)		210					
C7	Thrt before Lug%		75				75	
C8	<i>(not implemented)</i>		00				00	
C9	<i>(not implemented)</i>		00				00	
C10	Lug Start W		100				100	
C11	Lug End W		500				500	
C12	Lug Ramp up T & W		50				50	
C13	Lug Ramp dn T & W		50				50	
C14	<i>(not implemented)</i>		00				00	
C15	*Software version		*M03				*M03	
C16	*Hours work	*Hours total	00		*		*	

* = Read Only Function


Not used on Software M03

SOFTWARE VERSION M03 Rev 02

Copyright and rights are the property of Johnston Sweepers Ltd.

2 - USING THE PORTABLE PROGRAMMING UNIT (PPU)

The Johnston **D-Tec** portable programming unit (PPU) can also be used to set-up and tune the controller whilst the engine is running. To set-up the controller for adjustments, the following procedure should be adopted;



D-Tec programmer control interface

- (1) Insert the programmer unit connector lead into the communication (COMM) port which is found under the main cable socket. The port also provides power to the PPU.
- (2) The programming unit should briefly display the 'Zeta Banner' after the vehicle's ignition has been switched on and then show one of the parameters by name and value.
- (3) Using the three position rotary switch, set the parameter range to either **A**, **B** or **C** as desired.
- (4) Using the 16 position rotary switch, select a parameter **1** to **16** for alteration as desired, values prefixed with * cannot be adjusted and are 'read-only' features.
- (5) Only adjust the value of the parameters, not in bold type, with the up/down toggle switch.
- (6) Repeat steps (3), (4) and (5) for any other parameters that require alteration. Parameters may be altered in any sequence.
- (7) When the performance of the system is satisfactory press the red SAVE button to 'log-in' the set parameters.

IMPORTANT - DO NOT REMOVE THE 'COMM' PLUG OR SWITCH OFF THE IGNITION POWER UNTIL THE "PROGRAMMING" BANNER DISAPPEARS

- (8) When the message PROGRAMMING disappears and the unit displays the currently selected parameter, it may be disconnected from the controller.
- (9) The **SAVE** button may be pressed any number of times during a programming session, but **MUST** always be pressed after the final parameter is changed. Failure to press the **SAVE** button will cause the controller to revert to the previously saved setting when powering down.
- (10) In order to record and establish a basis for further adjustments, the parameter settings should be recorded on the log sheet for a particular vehicle, typically as shown on the previous page.

Copyright and rights are the property of Johnston Sweepers Ltd.

3 - PHYSICAL SET-UP PARAMETER ADJUSTMENT

The following notes pertain to the six physical adjustments required and the order sequence should be followed.

Firstly, select switch position **C15** and check the display reading is **T02** or above on D-Tec Z910, or **M03** and above on Z918. If not, check that the reading on switch position **A1** (with ignition only on) is **Model Number 910 or 918**. Check which model is required for your particular chassis by looking at the existing unit fitted.

A2 - Pulses per rev

The engine speed sensor has been re-positioned to read the pulses provided by the input shaft to the hydrostatic gearbox.

This means that for all VS Range of vehicles irrespective of chassis type the number of pulses will not vary. However, the operating functions do differ to previous models, the controller will no longer recognise that the engine is running until the hydrostatic gear box is selected together with the appropriate gear.

Remember to save the adjustments by pressing **SAVE** and to record the values on the log sheet.

B5 / C5 - MIN. PEDAL POSN / MAX. PEDAL POSN

These two parameters input to the **D-Tec** the physical characteristics of the foot pedal's in-built potentiometer in two conditions, one with the pedal fully relaxed and one with it fully depressed. As this component is a mechanical device it must be realised that variances in the potentiometer resistance (ohms) can be expected.

The set-up for **B5** is as follows;-

With the foot pedal fully relaxed and in its un-deflected state, look at the reading for 'pedal position' **A5**, then set the indicated value **+5 higher**, i.e. if the 'pedal position' reading is 24 at minimum position, then set **pedal min**, switch position **B5**, to 29. This ensures there is a small safety band and that the pedal has to be deflected a small amount before anything happens.

The set-up for **C5** is as follows;-

With the foot pedal fully deflected, look at the reading for 'pedal position' **A5**, then set the parameter to **-5 lower**, i.e. if the 'pedal position' reads 195 when fully deflected, then set **pedal max**, switch position **C5**, to 190.

Remember to save the adjustments by pressing **SAVE** and to record the values on the log sheet.

C2 - MINIMUM CURRENT

This parameter sets the minimum current output threshold to the transmission pump's proportional control. Ideally the current should be set as high as possible to a stage where once the foot pedal is deflected past its 'safety-band' setting, movement of the swash plate occurs. **Note:** **C2**, **B7** and **B8** cannot be set until the **HydroDrive** hydraulic system has been primed and the system working mechanically with the wheels turning hydrostatically. They should be left at the default settings.

The procedure for setting **C2** is as follows;-

With the engine running and all systems active (Hydrodrive in operation), set the machine into Forward Work Mode and with the PPU unit adjust the **C2** parameter in steps until a 'clutch-bite' condition occurs, i.e. a condition when the wheels start to turn and the machine just wants to move. Now repeat the test in reverse and note the reading. The lower of the two readings should then be **reduced by 5** to establish the correct setting for **C2**. Conduct the procedure several times to ensure an average condition for **C2** is established. The procedure should also be reconducted on level ground and after a period of running or warm-up.

Remember to save the adjustment by pressing **SAVE** and to record the value on the log sheet.

Please note that the pre-programmed default value is **3**, but from experience this has been found to vary on occasions.

B7- MAXIMUM CURRENT WORK FORWARD

Select the parameter **B7** and increase the reading to 120. Press save and record the setting on the Log Sheet.

B8 - MAXIMUM CURRENT WORK REVERSE

Select **B8** and input the figure in **B7** above.

4. TROUBLESHOOTING

There are various diagnostic functions that can be carried out to ensure the D-Tec and its connections are functioning correctly.

Firstly, check the indication on the LED's as detailed in Chapter 20 and that **C15** on the PPU reads software **T02** on D-Tec Z910 or **M03** or above on Z918.

There are diagnostic facilities on the Programmer (PPU) which enables you to view the input signals being received from various input sources.

Using the PPU select position **C3**, with the unit plugged in, ignition switched on and hydrodrive selected, the following readings should be seen.

<u>Switch Input</u>	<u>Value on C3</u>
Neutral (hydrodrive gear selector)	32 (work mode engaged)
Forward selected	2
Reverse selected	1
Foot brake signal	64

Please note that these figures can be built up in any combination.

i.e. Work Mode and Forward Drive
 32 + 2 = 34
If foot brake is then pressed reading = 34 + 64 = 98

Additional input signals are:

Accelerator - Select position **A5**, with ignition turned on the reading will increase from the min position (about 25) to the max position (about 190) as the pedal is pressed - this confirms that the pedal and wiring are all satisfactory.

Engine Speed Sensor - Select position **A1**, with the engine running and hydrodrive selected, (ensure chassis gearbox 1:1) the engine rpm should be displayed. This confirms that the speed sensor is in order. This information confirms continuity of signals and wiring to the D-Tec controller.

D-Tec Output - Using the PPU select switch position **A4**, engine running, select Forward, with handbrake applied note the reading on **A4** (probably about 4mA). As the accelerator pedal is pressed the pump will try to drive and the current going to the EDC on the pump can be measured, it should achieve the reading shown in **B7**.

This confirms that a current is going to the transmission pump to drive the machine.

HydroDrive Transmission System

***Set-Up and Commissioning Procedure
For
Truck Mounted Units***

***D-Tec Version 04 Onwards Software
Employing Sauer Sundstrand Hydrostatic
Transmission Components***


1 - INTRODUCTION

The purpose of this booklet is to provide guidance and set-up data for commissioning the hydrostatic transmission components associated with the Johnston **HydroDrive** system. The data is specific to truck chassis based sweepers when employing Sauer Sundstrand transmission equipment and the Johnston **D-Tec** control system.

It is presumed that in commissioning, the selection of the chassis and its characteristics along with the **HydroDrive** system would have already been predetermined and installed to the relative guidelines. This Chapter only gives details on the set-up and adjustments required to the hydrostatic pump and motor together with associated components.

2 - INITIAL SET-UP PROCEDURES

When starting the chassis engine and engaging the Hydrostatic gearbox for the first time from a 'dry-start' for commissioning and set-up, the following procedures must be adhered to;-

1. Jack-up the rear wheels and secure on axle stands and fully chock both front wheels.
 Suitably guard/fence off the machine to ensure no personnel can inadvertently walk into the revolving rear wheels.
2. Fill hydraulic reservoir to the middle of the sight glass with Shell Tellus T46 oil or equivalent.
Note: Hopper resting on prop.
3. Remove the top cap of the boost canister and fill with filtered oil. The oil will drain into the pumps, at the same time displacing air, so the canister will require topping-up several times. It may take some time before the oil in the canister maintains its correct level (i.e. covering the filter) at which time the top can be replaced and tightened.
4. Attach a suitable 0-25 bar gauge via an extension tube to the test point **T4**, refer to section 23 of the Technical Manual for test point location.
5. On the clutch system a mechanical switch has been fitted that is made when the clutch is pressed.
6. With chassis gearbox in neutral, start chassis engine to ensure air pressure is present (7.5 bar) 108 PSI.

Note: On new machines, or after repairs check, to select **HydroDrive** gearbox press the appropriate switch **W** and the warning lights **H** and **D** should illuminate. If the warning lights do not come on, simply select 1st gear, release the clutch to its bite point and the **HydroDrive** gearbox will engage and the emblem illuminate. **DO NOT** fully release the clutch.

7. Having engaged **HydroDrive** keep the clutch depressed. Select 1st gear on the chassis lift the clutch for no more than 20 seconds. Wait a short while then repeat. Keep repeating this process until the gauge connected to **T4** starts to show a pressure. Depending on the ratio of the chassis gearbox the pressure may vary. In order to achieve a higher pressure, one may need to progressively increase the speed by changing gear i.e. 2nd - 3rd etc. until 24 bar is achieved. Top up hydraulic tank if necessary.



If the clutch is released while the *HydroDrive* is engaged and any gear selected on the chassis gearbox, the front prop shaft will be turning

8. To operate the transmission motor that drives the rear wheels, select the correct gear that gives 1:1 ratio.
Release the handbrake, activate the master switch next to the drive selector. This will increase the chassis engine rpm to the lower speed limit of 1100 rpm.
Ensure all other switches are in their off position - select forward using the drive select switch. Progressively press the pedal until the rear wheels start to rotate.
Allow the wheels to rotate slowly for a short while then return the drive select to neutral and allow the wheels to stop. Select reverse and again allow the wheels to rotate slowly, for a short while. During this process keep an eye on the oil level - top up as required.
9. Alternating between forward and reverse, repeat this process six times.

Note: At all times the pressure on the gauge for **T4** should be maintained at approximately 24 bar.

The 1:1 ratio can be verified by checking switch position A1 on the **D-Tec** with the truck engine rev counter.

3 - PUMP SET-UP - RELIEF VALVE SETTINGS

Pressure setting -

Maximum forward - 420 bar - test point **T3**

Maximum reverse - 350 bar - test point **T1** anti skid block.

Attach suitable 0-500 bar gauges via an extension tube to the test points **T1** and **T3**, refer to section 23 of the Technical Manual for test point locations.

Pump Set Up continued:

1. With the vehicle jacked-up and secured on axle stands and both front wheels fully chocked - engage the **HydroDrive** and select the 1:1 ratio.
2. Release the clutch and increase the engine rpm to the maximum 1700. Keep handbrake applied, select forward using the drive select control, depress the accelerator pedal and read the pressure from test point **T3**,
3. Then select reverse and read the pressure from test point **T1**.

Note: The forward and reverse relief valves are located adjacent to the filter on the transmission pump. The top valve is for reverse (350 bar) and the lower for forward (420 bar). Adjustments are made by turning the valves clockwise to increase the pressure and counterclockwise to reduce it. See Figure ? of the Technical Manual. Now ensure **C2**, **B7** and **B8** have been set before proceeding.

4 - PUMP - CONTROL SYSTEM CHECKS

The pump is equipped with an electronically controlled proportional control valve which acts to convert an electrical current (mA) input into a hydraulic servo control pressure. In order to check that this function is operating correctly, a pressure signal of 8-18 bar should be recorded at test point **T2** with accelerator pedal fully relaxed or fully deflected.

5 - ANTI SKID MODULE SET-UP


1. Fit a 400 bar minimum pressure gauge on test point **T1** adjacent to the valve on the anti skid block
2. Disconnect and remove the electrical connection from the valve (RL) and energise the valve from a remote battery/supply.
3. With **HydroDrive** engaged, select reverse using the joy stick, (the chassis gearbox in 1:1 drive on a manual gearbox or **D** on an automatic gearbox) and the parking brake applied, depress the go pedal to its maximum position and read the pressure on the gauge. Adjust the relief valve **CT2** on the antiskid module required to achieve a nominal 200 bar setting.

6 - MOTOR SET-UP - PRESSURE CONTROL ADJUSTMENT

The motor is equipped with two in-built pre-set control features: (1) to instigate a decrease in the motor displacement resulting from a signal from the main control valve in the pump, this control is called the threshold control. (2) a pressure compensator valve that increases motor displacement when higher circuit pressures occur, this control is called the pressure compensator override (PCOR). Both these controls are pressure sensitive and factory set and on this basis should not be adjusted. However, to ensure conformity we like to check the displacement actuation pressure. This is achieved by connecting suitable pressure gauges (40 bar) to test point **T4B** with hydrodrive engaged, handbrake released, select forward drive and using the hand held PPU on position **C2**, slowly increase its value until a road speed of between 8-10 km/h is reached, at the same time observing the reading on pressure gauge, it should be 24 bar, until 8-10 km/h is reached. At this point the pressure should start to reduce.

The object of this test is to ensure the pump boost pressure (24 bar) is maintained until the speed criteria is achieved when motor displacement starts to change.

Section of Sauer Variable Displacement Motor



- | | |
|----------------------------------|---------------------------------|
| 1 Control Pressure Port | 7 Tapered Roller Bearings |
| 2 Hydraulic Proportional Control | 8 Synchronizing Shaft |
| 3 Pressure Compensator Override | 9 Piston |
| 4 Minimum Displacement Limiter | 10 Change Pressure Relief Valve |
| 5 Valve Segment | 11 Servo Piston Cylinder |
| 6 Bearing Plate | |

7 - COMPLETION OF SETUP

Remove guarding. Lower the vehicle off the axle stands and road test the vehicle in hydrostatic drive to confirm 40 kph can be achieved along the flat and that the vehicle can climb hills in Forward and Reverse. Please note max speed in reverse along the flat is restricted to 10 kph approx.

CHAPTER **16**

Warranty

Table of Contents	
Section	Page
Warranty	
Warranty	16 : 2

Copyright and rights are the property of Johnston Sweepers Ltd.

1 WARRANTY TERMS AND CONDITIONS

Johnston Sweepers Limited (JSL) undertakes to repair or replace, free of charge, any part manufactured by it which is proved to be defective through inadequate workmanship or materials during the first two thousand hours of operation, or within a period of twelve months (whichever is the sooner) from the date of delivery from JSL unless the warranty is registered to the buyer (the Customer) through our website at http://www.johnstonsweepers.com/warranty_registration.asp. This warranty is not transferable. Any original equipment part replaced at JSL cost carries the remaining period of warranty for any defective material or workmanship. Qualifying parts fitted outside the JSL machine warranty period carry a twelve months parts only warranty for defective material or workmanship.

Warranty is given subject to the following conditions:

- a) The machine shelf life of 6 months has not been exceeded. "Shelf Life" means time stored in good condition by the distributor from the date on which the product was despatched by JSL. For spare parts the shelf life is 1 year.
- b) A suitable working area is provided for the work required.
- c) Adequate written notice of the defect is submitted to JSL within 30 days of the discovery of the defect. This must include a written detailed report describing the problem, the circumstances applying at the time and any additional relevant information. The report must contain sufficient information to allow JSL to understand the problem and action taken. Claims relating to damage incurred during delivery to the Customer must be notified within 24 hours of receipt of the equipment.
- d) Defective parts are held by the Customer until disposal has been authorised by JSL. If JSL requests the return of the parts then JSL will pay reasonable carriage charges.
- e) The defect has not been caused by carelessness, vandalism, accident, incorrect maintenance, improper operation, abnormal working conditions, tampering with sealed settings, failure to follow JSL's instructions, inadequate lubrication or fair wear and tear.
- f) For parts not manufactured by JSL, no attempt shall have been made to dismantle or repair the parts without the written approval of the relevant manufacturer, JSL, or an authorised agent of either.

Replacement parts for warranty claims shall be purchased and a claim submitted to recover costs. Parts replaced under warranty will be credited along with carriage charges for that item. JSL will not pay any Customer profit element on parts replaced under warranty.

JSL will not be liable for replacement of any parts designated as consumable items (see separate list, available on request), for fuel, hydraulic fluid, antifreeze or lubricants used in maintenance or warranty work, downtime or for any consequential loss or charges, including transportation or recovery charges.

As JSL are not authorised repairers of engines or proprietary chassis' JSL are unable to accept any claims relating to them. JSL will therefore pass on to the customer the benefit of any warranty provided by the manufacturers in respect of them and as such any repairs or claims should be submitted to the manufacturer or its locally appointed agent. Any claim received by JSL for such repairs will be forwarded to the relevant manufacturer for their acceptance before it is credited.

This warranty applies only to the original equipment supplied by JSL and genuine Johnston spare parts. It shall not apply to unauthorised alternative parts or materials or any consequential damage or failure resulting from the use of fitting of such parts or materials.

Provided that the claim is justified and that the correct procedure has been followed, claims will be paid within 30 days of receipt. Offset of claims against sums due to Johnston is hereby specifically prohibited.

ENGINES

The standard warranty from the engine's supplier is passed on in full without reduction as specified in the engine manufacturers standard Terms and Conditions.

FUELS

In line with the engine manufacturers specifications all fuel used must be in line with EN590:1993 and can incorporate a maximum of 5% Bio-diesel.

2 CONSUMABLES LIST

Body Inlet Ducts, Flaps and Meshes
Brush Linkages, Bushes and Pivots
All Sweeping Brushes
Drive Couplings, Bearings and Belts
Curtains and Mudflaps
Filters and Elements
Impellers and Casings
Supawash Hoses, Jets, Lances and Fittings
Lift Cables
Light Bulbs and Fuses
Nozzles, Nozzle Wheels and/or Skids, Guards, Rubbers and Retaining Strips,
Nozzle and Wanderhose Trunkings
Seals and Rubbers
Tyres and Friction Materials
Wanderhose Turrets, Ducts, and Bearings
Water Jets
Water Pump Pistons, Diaphragms, Seals and Rotors
Wearing Plates, Strips and Baffles
Windows, Mirrors and Inspection Glasses
Any other items normally regarded as consumables

3 EXTENDED WARRANTY OPTIONS

JSL offer 2 extended warranty options, Silver or Gold to cover the whole machine (excluding proprietary chassis) for upto 3 years, or 6000 hours, whichever the sooner..

- The Silver Warranty provides full cover for year 2, upto 4000 Hours
- The Gold Warranty provides full cover for years 2 and 3, upto 6000 Hours

All other terms and conditions are as described above.

YOUR COMMITMENT

In order to register your warranty please complete and return the form below.

I have read the Warranty Terms and Conditions as shown above and understand that the equipment must be operated and maintained in accordance with requirements of this warranty to retain entitlement to its benefit. Any failure to comply with conditions shown above renders this warranty null and void and the standard 12 month warranty then applies.

(tick as appropriate)

This form registers the Standard Silver Gold warranty for the following vehicle.

To register the date into service, please complete and return.

Model _____

Delivery Date _____

EQ No _____

Registration No _____

Signed by or on behalf
of the Purchaser

Name

Position

Date

The vehicle is located at

The vehicle is serviced / maintained at the following depot

Depot Manager details

Name

Telephone

Fax

Please forward the completed form to the Warranty Department at the following address:

JOHNSTON SWEEPERS LIMITED
CURTIS ROAD
DORKING
SURREY
RH4 1XF

TEL: +44 (0)1306 884722

FAX: +44 (0)1306 740369

e-mail: warranty@johnstonsweepers.com

Rev. 11 doc

01.11.07.

Copyright and rights are the property of Johnston Sweepers Ltd.

CHAPTER 17

Health and Safety

Introduction

The information presented in this chapter does not infer that there are hazards associated with the Johnston sweepers. It is given as a guide to general precautions that should be exercised in the course of their maintenance work.

Whilst every effort has been made to ensure completeness of this document, owners and operators of Johnston sweepers are reminded of their responsibilities to comply with all relevant legislation including Risk/COSHH Assessments and Approved Codes of Practice.

HEALTH AND SAFETY PRECAUTIONS

The information presented in this section does not infer there are any particular hazards associated with these machines. It is given as a guide to the general precautions that should be taken in any workshop environment when working on machines of this nature in the course of their maintenance.



Safety symbol:

The universal symbol is used throughout this manual to indicate information which is essential for health and safety of all operating personnel.

Refer to all state, district/company, or council Health and Safety Regulations and follow the procedures laid down.

The repair and maintenance of machinery such as this can involve physical hazards or other risks to health. This section lists some of these hazards and the precautions necessary to avoid them.

The list is only general but all other operations, procedures and the handling of materials should be carried out in accordance with the requirement of health and safety laws, which is the responsibility of the Owner/Operator/Maintainer.



Sharp objects warning:

There can be a risk of injury from sharp objects such as discarded hypodermic needles becoming lodged in the sweeping system. The use of 'needle stick gloves' is recommended when changing brushes, using the wanderhose/Littasnatch and when cleaning out the machine.




Anti Freeze:

Anti-freeze may be absorbed through the skin in toxic or harmful quantities. If swallowed, seek medical attention immediately. Some types, i.e., isopropanol, ethylene glycol and methanol are flammable.



Batteries:

Gases released during charging are explosive. Never use naked flames or allow sparks near charging or recently charged batteries.



Disconnection:

Disconnect the negative battery lead from battery first. The positive cable must always be disconnected last.

Reconnection:

Always reconnect the positive battery cable first.

Jump-starting and use of auxiliary (booster) batteries:

Do not jump-start maintenance free batteries if in a deeply discharged state as internal short circuits may occur.

If a maintenance free battery is found to be in a deeply discharged state, it is essential to remove the battery and recharge off the vehicle. Jump-starting will not enable the vehicles own charging system to initiate the charging process.

Jump starting procedure:

Always follow this procedure when connecting a booster battery.

Take care not to cause sparking which could ignite hydrogen gas being given off by the batteries.

1. Apply the park brake, turn off ignition, lights and other electrical loads.
2. If the slave battery is mounted on another vehicle, ensure that the vehicles are not touching.
3. Ensure that the donor battery voltage is compatible with the vehicle battery.
4. Ensure that adequate ventilation is available to the vehicle and slave batteries.
5. Connect positive terminal of the donor battery group to positive terminal of the discharged battery group.
6. Connect negative terminal or slave battery group to chassis earth of the discharged battery group.
7. Attempt to start the casualty vehicle.
8. Once the vehicle has started, remove the negative lead from the chassis and then the slave battery.
9. Remove positive lead from discharged chassis and then the donor chassis.

If the vehicle will not start with a booster battery, contact your local Johnston Service Network.

Chemical materials:

Chemical materials such as solvents, sealers, adhesive, paints, resin foams, battery acids, anti-freezes, brake fluids, oils and grease should always be used with caution and stored and handled with care.

Chemical materials may be toxic, harmful, corrosive, irritant or highly flammable and give rise to hazardous fumes and dust.

Always consult the appropriate safety standards for handling such materials.



Typical biohazard symbol



Typical radioactive material symbol



Typical poison symbol



Always use appropriate protective clothing

**REMINDERS**

Chemical materials

- DO** remove chemical materials from the skin and clothing as soon as practical after soiling. Change heavily soiled clothing and have it cleaned.
- DO** carefully read and observe hazard and precaution warnings given on hazardous material containers and in any accompanying leaflets, posters or other instructions. Hazardous material health and safety data can be obtained from manufacturers.
- DO** organise work practices and use protective clothing to avoid soiling of the skin and eyes; breathing vapours, aerosols, dust, and fumes; inadequate container labelling; fire and explosive hazards.
- DO** wash before job breaks, before eating, smoking, drinking or using toilet facilities when handling chemical materials.
- DO** keep work areas clean, uncluttered and free of spills.

- DO NOT** mix chemical materials except in accordance with the manufacturer's instructions. Some chemicals can form other toxic or harmful substances; give off toxic or harmful fumes; be explosive when mixed together.
- DO NOT** spray chemical materials, particularly those based on solvents, in confined spaces; for example, when people are inside a vehicle.
- DO NOT** apply heat or flame to chemical materials, except under the manufacturer's instructions. Some are highly flammable and some may release toxic or harmful fumes.
- DO NOT** leave containers open. Fumes given off can build up to toxic, harmful or explosive concentrations. Some fumes are heavier than air and will accumulate in confined areas, pits, etc.
- DO NOT** transfer chemical materials to unlabelled containers.
- DO NOT** clean hands or clothing with chemical materials. Chemicals, particularly solvents and fuels will dry the skin and may cause irritation with dermatitis. Some can be absorbed through the skin in toxic or harmful quantities.

**Dusts:**

Powder, dusts or clouds may be irritant, harmful or toxic. Avoid breathing dusts from powdery chemical materials or those arising from dry abrasion operations.
Wear respiratory protection in accordance with the requirement of the Health and Safety Acts.

**Electric shocks:**

When working on electrical systems, remove watches, bracelets and rings as these can conduct electricity and cause shorts and/or burns.

Electric shocks can result from the use of faulty electrical equipment or from the misuse of equipment even in good condition.

Ensure that electrical equipment is maintained in good condition and frequently inspected and tested.

Ensure that flexes, cables, plugs and sockets are not frayed, kinked, cut, cracked or otherwise damaged.

Ensure that electrical equipment is protected by the correct rated fuse and if used outside an earth-leakage circuit breaker is used.

Never misuse electrical equipment and never use equipment that is in any way faulty. The results could be fatal.

Use reduced voltage equipment (110 or 24 volt) for inspection and working lights where possible.

Ensure that the cables of mobile electrical equipment cannot be trapped and damaged such as in a vehicle hoist, trolley jacks, etc.

Use air operated mobile equipment where possible in preference to electrical equipment.

**Exhaust fumes:**

These contain asphyxiating, harmful and toxic chemicals and particles such as carbon oxides, nitrogen oxides, aldehydes, leads and aromatic hydrocarbons.
Engines should only be run under conditions of adequate extraction or general ventilation and not in confined spaces.

NB : Catalyst exhausts/silencers can run at extremely high temperatures.

**Fire and welding:**

Observe strict fire safety when storing and handling flammable materials or solvents, particularly near electrical equipment or welding processes.

Disconnect battery, microprocessors, etc. before commencing welding. Failure to observe this could cause failure of components.

Ensure before using electrical or welding equipment that there is no fire hazard present.

Have a suitable fire extinguisher available when using welding or heating equipment.

Special precautions must be taken before any welding or cutting takes place on vessels which have contained combustible materials, e.g. fuel tanks.

The sound insulation foam used on the equipment must be removed if any welding is to be carried out in that area of the machine.

**First aid:**

It is desirable for someone in the workshop to be trained in the first aid procedures. Splashes or particles in the eye should be flushed with clean water for at least ten minutes and medical attention sought. Soiled skin should be washed with soap and water. Inhalation affected individuals should be removed to fresh air immediately. If hazardous material has been swallowed or if the effects of exposure to hazardous materials persist, consult a doctor with information (label) on material used. Do not induce vomiting (unless indicated by the manufacturer).

**High-pressure air and lubrication equipment:**

Always keep high-pressure equipment in good condition and regularly maintained, particularly at joints and unions.

Never direct a high (or low) pressure nozzle at the skin as the fluid may penetrate to the underlying tissue, etc, and cause serious and potentially fatal injury.

**Oils and greases:**

Prolonged and repeated contact with mineral oil may result in the removal of natural fats from the skin, leading to dryness, irritation and dermatitis. Gross and prolonged contact, especially with used engine oil, which contains potentially harmful contaminants, may cause skin cancer.



Where there is a risk of eye contact, e.g., by splashing, eye protection should be worn, for example, chemical goggles or face shields; in addition, an eyewash facility should be provided.

Adequate means of skin protection and washing facilities should be provided.

Repeated or prolonged skin contact should be avoided by wearing protective clothing, including impervious gloves where practical. Particular care should be taken with used oils and greases containing lead.

First Aid treatment should be obtained immediately for open cuts and wounds.

Apply barrier cream before each work period to help when removing oil from the skin.

Use proprietary hand cleaners only if they can be removed from the skin using water.

Overalls must be cleaned regularly. Discard clothing that cannot be cleaned and footwear that has become impregnated.

In the event of a skin condition occurring consult a doctor and tell him/her that your work involves using oil.

Solvents:

Solvents such as acetone, white spirit, toluene, xylene and trichloroethane are flammable.



Avoid splashes to the skin, eyes and clothing. Wear protective gloves, goggles and clothing.



When using solvents ensure good ventilation; avoid breathing fumes, vapours, spray-mists and keep containers tightly sealed. Do not use in confined spaces. When spraying materials containing solvents, for example paints, adhesives or coatings, use extraction ventilation or personal respiratory protection in the absence of adequate general ventilation.

Do not apply heat or flame except under specific and detailed manufacturer's instructions.



Suspended loads:

Never work under an unsupported, suspended or raised load. For example, jacked up vehicle, raised tipper body, suspended engine, etc.

Always ensure that lifting equipment e.g., jacks, hoists, axle stands, slings, etc are adequate and suitable for the job, in good condition and regularly maintained.

NEVER improvise lifting tackle. **ALWAYS** ensure body props and/or axle stands are used when working under bodies or chassis.



Workshop tools and equipment:

Only use tools and equipment for their intended purposes.

Never overload equipment such as hoists, jacks, axles stands or lifting slings. Damage caused by overloading is not always immediately apparent and may result in a fatal failure the next time the equipment is used.

Never use damaged or defective tools or equipment.

Always wear suitable eye protection when using grinding, chiselling or air guns.



Always wear a suitable breathing mask when using sand blasting equipment, working with asbestos based materials (such as brake linings) or using spraying equipment.



ALWAYS use approved safety platforms/gantries when working above ground level.

